


**CHINO**

**AL4000/AH4000 Series  
KL4000/KH4000 Series**

**Hybrid Recorder**

[Parameter Setting Software/Parameter  
Switching Tool]  
(Multi-point type)



**INSTRUCTIONS**

**CHINO**

# Table of Contents

<b>1. Introduction .....</b>	<b>1</b>
<b>2. System Requirement .....</b>	<b>3</b>
2-1.    System Configuration.....	3
2-2.    Operating Condition of Software .....	3
<b>3. How to Setup .....</b>	<b>4</b>
3-1.    Installation .....	4
3-1-1.    New Installation .....	4
3-1-2.    Installation at Upgrade .....	6
3-1-3.    Installation of USB Driver.....	7
3-2.    Uninstallation .....	13
<b>4. Valid Value Range in Software .....</b>	<b>15</b>
<b>5. Startup and Exit of Software .....</b>	<b>16</b>
5-1.    Startup .....	16
5-2.    Exit .....	17
<b>6. How to Operate .....</b>	<b>18</b>
6-1.    Basic Rules.....	18
6-1-1.    How to Input Setting Values.....	18
6-1-2.    Inputting Characters and Alphanumeric.....	18
6-1-3.    Decimal Location .....	19
6-1-4.    Operation Flow .....	21
6-1-5.    Setting Items by Instrument .....	23
6-2.    Operation of Parameter Setting Menu Screen .....	25
6-2-1.    Offline (New) Setting .....	25
6-2-2.    Offline (File) Setting.....	26
6-2-3.    Online Setting .....	27
6-3.    Operation of Ethernet Adapter Setting Screen.....	28
6-4.    Operation of Serial Adapter Setting Screen .....	29
6-5.    Operation of USB Adapter Setting Screen .....	30
6-6.    Operation of Parameter Setting Screen.....	31
6-6-1.    Range Settings "Range" .....	33
6-6-2.    Alarm Settings "Alarm" .....	36
6-6-3.    Calculation Settings "Calc" .....	39
6-6-4.    Calculation Formula Settings "Formula" .....	42
6-6-5.    Broken Line Approximation Table Settings "Seg.Tbl" .....	44
6-6-6.    Chart Speed Settings "Chart" .....	46
6-6-7.    Analog Recording (Dot Printing Type) Settings "Dot".....	47
6-6-8.    Subtract Printing Settings "Sub Prt" .....	48
6-6-9.    Analog Recording (Trace Printing Interval) Settings "Dot.Int" .....	50
6-6-10.    Periodic (Data Interval) Data Printing Settings "Datalnt" .....	51
6-6-11.    Periodic (Specified Time) Data Printing Settings "PrtTime" .....	52
6-6-12.    Message Printing 1 Settings "MsgPrt1" .....	54
6-6-13.    Message Printing 2 Settings "MsgPrt2" .....	56
6-6-14.    Recording Format Settings "PrtForm" .....	57
6-6-15.    Automatic Range Switching (Printing) Settings "A.Range" .....	58
6-6-16.    Compressed/Expanded Printing Settings "Cmp&Exp" .....	60
6-6-17.    Zone Printing Settings "ZonePrt" .....	62
6-6-18.    SD Card Settings "SD CARD" .....	63
6-6-19.    USB Engineering Port Settings "USB" .....	65
6-6-20.    COM1 (Communication) Settings "COM1" .....	66
6-6-21.    COM2 (Communication) Settings "COM2" .....	67
6-6-22.    Ethernet Settings "Ether" .....	68
6-6-23.    SNTP Settings "SNTP" .....	69
6-6-24.    Email Address (Account) Settings "E-mail Account" .....	70

6-6-25.	Email Address (Destination) Settings "E-mail Address" .....	71
6-6-26.	Email Address (Sending Condition) Settings "E-mail Condition" .....	72
6-6-27.	Calendar Timer Settings "Timer" .....	73
6-6-28.	External Drive Settings "Dig Inp" .....	75
6-6-29.	Operation Recording Settings "Ope.Rec" .....	76
6-6-30.	Failout Settings "FailOut" .....	78
6-6-31.	Display Settings "Display" .....	80
6-6-32.	Date/Time Settings "Date" .....	82
6-6-33.	System Settings "System" .....	83
6-6-34.	Format Display .....	84
6-6-35.	Display Order Settings "D.Order" .....	85
6-6-36.	Soft Dip Switch Settings .....	86
6-7.	Operation of Help Screen .....	87
6-8.	Operation of Version Check Screen .....	88
<b>7. Parameter Switching Tool .....</b>	<b>89</b>	
7-1.	System Configuration.....	89
7-2.	Operating Condition of Software .....	89
7-3.	Installation .....	90
7-3-1.	New Installation .....	90
7-3-2.	Installation at Upgrade .....	92
7-4.	Uninstallation .....	93
7-5.	Startup and Exit of Switching Tool .....	95
7-5-1.	Startup.....	95
7-5-2.	Exit .....	95
7-6.	How to Operate .....	96
7-6-1.	Parameter Reading from Old Model Instrument.....	96
7-6-2.	Parameter Writing to New Model Instrument.....	98
7-7.	Parameter Switching.....	99
7-7-1.	Switchable Parameter Types .....	99
7-7-2.	Input Type Switching .....	100
<b>8. Glossary .....</b>	<b>102</b>	
<b>9. Troubleshooting.....</b>	<b>103</b>	

# 1. Introduction

Thank you for purchasing our hybrid recorder.

With this software, you can set various parameters on your PC by connecting the hybrid recorder (AL4000/AH4000, KL4000/KH4000) to the PC via communication interface (multi-point type only).

This instruction manual describes how to prepare hardware, install the program, and operate it. Make sure to read this instruction manual in advance in order to understand this software well and to prevent troubles from occurring.

## Note

1. Scope  
The following license terms apply to the CHINO product you purchased this time.
2. Copyright  
The copyright, trademark, expertise and all intellectual proper rights of this software are owned by CHINO.
3. Scope of license  
The software may be used only for the instrument you purchased. Within the scope of use, the software may be installed on more than one PC by more than one user.
4. Prohibition of use by the third party  
Without prior written consent of CHINO, you may not assign, sell, rent or lease this software and its copy.
5. Restriction on copying  
You may only make a copy of this software which is provided in the form of a storage medium for backup usage.
6. Prohibition of modification  
Without consent of CHINO, you may not alter or modify this software (including partial integration of this software to other software).
7. Warranty  
If this software does not operate properly at the time of your purchase, CHINO will replace it free of charge, except for the case where the malfunction is caused by erroneous operation or the PC.
8. Limitation of liability  
CHINO is not responsible for any damages caused by operation of this software.
9. Other  
Due to improvement or for some other reasons, the specifications of this software may be altered by CHINO without prior notice.

## Notice

1. No part of this manual can be reproduced or copied in any form without permission.
2. The contents of this manual may be altered without prior notice.
3. This manual has been documented by making assurance doubly sure. However, if any question arises or if any error, an omission, or other deficiencies are found, please contact your nearest our sales office.
4. CHINO is not responsible for any operation results of this software.

## Trademark

1. Microsoft, Windows, Windows XP, Windows Vista, Windows 7, and .NET Framework are trademarks of Microsoft Corporation and the related company.
2. SD Memory Card is the trademark of Panasonic Corporation, SanDisk Corporation in USA, and TOSHIBA CORPORATION.
3. Other described company names and product names are trademarks and registered products of the respective companies.
4. Please note that the marks "TM" and "®" are omitted throughout this manual.4. Please note that the marks TM and ® are omitted throughout this manual.

## Precautions

1. Be careful not to drop the software when taking it out of the package.
2. If not used for a long time, keep the software in a CD case after installation and store it at room temperature, away from dust.
3. Keep this instruction manual carefully until the software is discarded.
4. When discarding the software, follow the local regulations for waste disposal and cooperate in recycling.

### ■ Checking before use

After opening the package of this software, be sure to check the following before use. If you have found any problems, please contact the dealer where you purchased the product or the nearest sales office of CHINO.

1. Appearance  
Check the appearance of the product to see if there is any damage.
2. Label  
Check that the model written on the label is correct.

## Cautions for handling the CD-ROM


1. Eject the CD-ROM media from the drive when not used.
2. Be sure to keep the disk in a CD case.
3. Keep the disk away from direct sunlight, high temperature and humidity.
4. Keep the signal side clean from fingerprints, dirt, dust, scratches and water drops.

## 2. System Requirement

Use the software in the environment described below.

### 2-1. System Configuration

To use the software, the PC and the instrument should be connected one-to-one with an appropriate cable for the communication type.



### 2-2. Operating Condition of Software

Required instruments	Contents and conditions	
PC	CPU	1GHz 32 bit or 64 bit.
	Memory	1GB or more (32bit), 2GB or more (64bit).
	Hard disk space	2GB or more free hard disk space.
	Disk drive	CD drive.
	Removable disk drive	Compatible with SD memory card.
	Supported OS	Windows XP SP3 (32bit) Windows Vista SP2 (32bit/64bit) Windows 7 (32bit/64bit) * .NET Framework 3.5 or later must be able to be installed on the OS.
	Communications interface	USB Serial Ethernet (at least one of them is required).
Required library	.NET Framework3.5	
Display	Screen resolution 800 x 600 or more.	
Printer	Compatible with Windows.	
Mouse	Compatible with Windows.	
Keyboard	Compatible with Windows.	
Target instrument	AL4000/AH4000, KL4000/KH4000 one unit * Multi-point type only.	

### 3. How to Setup

#### 3-1. Installation

##### 3-1-1. New Installation

Install the software from the CD-ROM to the PC before using it.

Use the following procedure for installation.

##### <Procedure>


###### (1) Insert the CD-ROM

Start Windows, and then insert the CD-ROM into the CD-ROM drive. The menu screen is started automatically.

\* If the menu screen is not started automatically, start "asmenux.exe" in the CD-ROM.

###### (2) Click the [Parameter Configuration Software] button


Click the [Parameter Configuration Software] button on the Hybrid Recorder Software Install Menu screen.



###### (3) Accept the license terms (If .NET Framework 3.5 is already installed, go to step (4))

When the Microsoft Software Supplemental License Terms (.NET Framework 3.5) is displayed, read the contents carefully. If you accept them, click the [Accept] button. This will start the installation of .NET Framework 3.5 (this process may take several minutes). If you click the [Don't Accept] button, you cannot use this software.

\* The license terms may not be displayed when .NET Framework 3.5 is already installed.




**(4) Click the [Next] button**

The Parameter Configuration Software Setup Wizard screen is started. Click the [Next] button.




**(5) Click the [Next] button**

On the Confirm Installation screen, click the [Next] button.




**(6) Start the installation**

The installation is started. The screen indicating the progress of installation appears. Wait until the installation is completed.



## (7) Complete the installation

The installation complete screen appears. Click the [Close] button to finish.



### 3-1-2. Installation at Upgrade

This software is sometimes upgraded to add newly supported instruments or to fix issues.  
Use the following procedure for version upgrade.

#### <Procedure>

- (1) Uninstall the current version (refer to section 3-2).
- (2) Install the new version (refer to section 3-1-1).

#### Remarks → About uninstallation for version upgrade

- The uninstallation should be done from the [Program and Features] dialog box in Windows as described in "3-2. Uninstallation".  
You cannot complete the uninstallation by simply deleting the files (moving them to the "Recycle Bin").
- Do not delete the folder during an uninstallation for version upgrade.

### 3-1-3. Installation of USB Driver

If you connect your PC to the instrument via a USB cable, you need to install the USB driver.  
Use the following procedure for installation.

#### <Procedure>

##### • When Using Windows XP or Windows Vista (Screenshots of Windows XP are used.)

\* We use screenshots of Windows XP for description. This procedure is the same as that for Windows Vista in principle.

##### (1) Start the Found New Hardware Wizard

When you connect the USB cable, the Found New Hardware Wizard is started automatically. Select [No, not this time], and click the [Next] button.




##### (2) Select the installation method

The installation method selection screen appears. Select [Install from a list or specific location (Advanced)], and click the [Next] button.



##### (3) Specify the search location

On the search and installation option selection screen, select [Search for the best driver in these locations], check the [Include this location in the search] check box , and then click the [Browse] button.




#### (4) Select the folder

When the [Browse For Folder] dialog box appears, select a file below depending on the OS you use, and then click the [OK] button (if you cannot find the folder, click [My Computer] → [C:] → [CHINO] → [ParamSet] → [32bit]).  
\* For 64bit version Windows Vista, click [64bit].



#### (5) Click the [Next] button

When you specified the search location, click the [Next] button.



#### (6) Start the installation

The installation is started. The screen indicating the progress of installation appears. Wait until the installation is completed.



#### (7) Complete the installation


The Completing the Found New Hardware Wizard screen appears. Click the [Finish] button to finish.



## • When Using Windows 7


### (1) Open the Control Panel

After connecting the USB cable, click [Start] → [Control Panel].




### (2) Click [System and Security]

When the Control Panel is displayed, click [System and Security].




### (3) Click [Device Manager]

When the System and Security screen is displayed, click [Device Manager].




### (4) Click [Unknown device]

When the Device Manager screen is displayed, click [Other Devices], and then [Unknown device].




**(5) Click [Update Driver Software]**

Right-click [Unknown Device], and then click [Update Driver Software] on the displayed menu.



**(6) Click [Browse my computer for driver software]**

On the screen for selecting how to search the driver software, click [Browse my computer for driver software].




**(7) Specify the search location**

On the Browse for driver software screen, select the [Include subfolders] check box , and then click the [Browse] button.



**(8) Select the folder**

When the Browse folders screen is displayed, select [USBDriver] (if you cannot find [USBDriver], click [Computer] → [(C)] → [CHINO] → [ParamSet] → [USBDriver]). Confirm that [USBDriver] is selected in the [Folder (E):] field, and then click the [OK] button.



**(9) Click the [Next] button**

When you specified the search location, click the [Next] button.



**(10) Click [Install] or [Install this driver software anyway]**

One of the following screens is displayed.

Follow the instruction for the displayed screen.

**• For the Windows Security screen (a)**

Click the [Install] button to start the installation.


**Windows Security screen (a)**



**• For the Windows Security screen (b)**


Click [Install this driver software anyway] to start the installation.

**Windows Security screen (b)**




### **(11) Start the installation**

The installation is started. The screen indicating the progress of installation appears. Wait until the installation is completed.



### **(12) Complete the installation**

The driver software update completion screen is displayed. Click the [Close] button to finish.



## 3-2. Uninstallation


This section describes how to delete the software from the hard disk.

Exit all programs related to the software before starting the uninstallation.

### <Procedure>

#### (1) Open the Control Panel

Click [Start] → [Control Panel].




#### (2) Click [Uninstall a program]

When the Control Panel is displayed, click [Uninstall a program].




#### (3) Delete [Parameter Configuration Software]

Select [Parameter Configuration Software] from the list displayed in [Uninstall or change a program], and then click [Uninstall].



**(4) Click [Yes]**


On the Program and Feature screen, click [Yes].



**(5) Start uninstallation**

The uninstallation is started. The screen indicating the progress of uninstallation appears. Wait until the uninstallation is completed. When the uninstallation is completed, the screen shown right is closed automatically.

- \* At this point, the folder related to the software still remains. To completely delete the software, delete the installation folder "ParamSet" using the Windows Explorer. The location of the folder is shown in the table below.



**[Location of the folder related to the software]**

OS	Location of folder
Windows XP	C:\Documents and Settings\[user name]\Application Data\CHINO\ParamSet\
Windows Vista, Windows 7	C:\Users\[user name]\AppData\Roaming\CHINO\ParamSet\

**Remarks**

**About uninstallation for version upgrade**


- You cannot complete the uninstallation by simply deleting the files (moving them to the "Recycle Bin").
- Do not delete the folder during an uninstallation for version upgrade.

## 4. Valid Value Range in Software


The following figures show the range of value that can be handled by the software and the instrument.

### 1. Valid Value Range in Parameter Configuration Software (or PC) and Instrument:-30000 to 99999

The PC and the instrument can handle values in the range -30000 to 99999.




PC



Instrument

### 2. Valid Value Range Set via Communication:-30000 to 30000


When being sent via communication, values in the range 30001 to 99999 are handled as overflow.



- (1) When a value in the range 30001 to 99999 is sent from the instrument to the PC, the overflow value (#####) is displayed on the PC.
- (2) When a value in the range 30001 to 99999 is sent from the PC to the instrument, it is invalid on the instrument, and the previous value is retained.

### 3. Valid Value Range Set via SD Card:-30000 to 99999

When being set via SD card, the same range of values can be handled as the PC and the instrument themselves can handle.



- (1) When you save a value in the range -30000 to 99999 which is edited on the instrument to an SD card and read it on the PC, it is displayed as a value in the range -30000 to 99999.
- (2) When you save a value in the range -30000 to 99999 which is edited on the PC to an SD card and read it on the instrument, it is displayed as a value in the range -30000 to 99999.

#### Reference ➤ Setting and editing a value in the range 30001 and 99999

You cannot set a value in the range 30001 to 99999 via communication.

If you want to set/edit a value in the range 30001 to 99999, use an SD card.

# 5. Startup and Exit of Software


## 5-1. Startup

This section describes how to start up the software.

### <Procedure>


#### (1) Display all programs

Click [Start] → [All Programs].




#### (2) Click [Parameter Configuration Software]

Next, click [CHINO] → [Configuration&Migration] → [Parameter Configuration Software] to start up the software.



#### (3) Open the Parameter Setting Menu screen

The Parameter Setting Menu screen appears. Set the parameters depending on your instrument (refer to section 6).




## 5-2. Exit

This section describes how to exit the software.

### <Procedure>


#### (1) Click the [X] button on the Parameter Setting screen

Click the [X] button on the right side of the title bar to close the Parameter Setting screen.



#### (2) Click the [Exit] or [x] button on the Parameter Setting Menu screen

Click the [Exit] or [x] button on the Parameter Setting Menu screen to exit the software.



# 6. How to Operate

## 6-1. Basic Rules






This section describes generally common items for setting operations.

**Remarks** **Instruction manuals for the instrument**

For AL4000/AH4000, this refers to the instruction manual.

### 6-1-1. How to Input Setting Values

You can enter a setting value by selecting a setting item and entering a value directly, selecting a value from a drop-down list, or entering a value in a field directly (see the table below).

Button	Description
	Click  button and select a value from the list.
	Enter a value directly or click  button to select a value.
	Enter a value directly.
	Click the check box <input checked="" type="checkbox"/> to clear it <input type="checkbox"/> , and enter a value directly or click  button to select a value.
	Enter a value directly, or select each value in the right and left fields and click  button to select a value.
	Click the check box <input type="checkbox"/> to select it <input checked="" type="checkbox"/> .
	Enter the date and time directly.

### 6-1-2. Inputting Characters and Alphanumeric

Only one byte alphanumeric characters can be used for a character or value.

Multi-byte characters can be entered temporarily, but they cannot be set by pressing the Enter key.

Multi-byte characters need to be converted to one byte characters before pressing the Enter key.

### 6-1-3. Decimal Location

When you change the decimal location in a setting value, the ones in other setting values are changed accordingly. The decimal locations of the alarm value for the alarm setting and the dead band are also changed with a decimal location change of the range in the range setup.

#### 1. When entering the voltage

- (1) If you change the decimal location of the range (Example:1→2)

■ : To be changed

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-500.0	500.0	1	-500.0	500.0	1	0.0	-500.0	500.0	1

↓

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-50.00	50.00	2	-50.00	50.00	2	0.00	-50.00	50.00	2

The decimal locations of the scale, sensor correction, and chart recording are changed with a decimal location change of the range.

Type	Alarm Value	Dead Band	→	Type	Alarm Value	Dead Band
Upper	-3276.8	0.0		Upper	-327.68	0.00

The decimal locations of the alarm value for the alarm setting and the dead band are also changed with a decimal location change of the range.

- (2) If you change the decimal location of the scale (Example:1→2)

■ : To be changed

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-500.0	500.0	1	-500.0	500.0	1	0.0	-500.0	500.0	1

↓

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-500.0	500.0	1	-50.00	50.00	2	0.00	-50.00	50.00	2

The decimal locations of the sensor correction and chart recording are changed with a decimal location change of the scale.

- (3) If you change the decimal location of the chart recording (Example:1→3)

■ : To be changed

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-500.0	500.0	1	-500.0	500.0	1	0.0	-500.0	500.0	1

↓

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-500.0	500.0	1	-500.0	500.0	1	0.0	-5.000	5.000	3

The decimal locations of the range, scale, and sensor correction are not changed with a decimal location change of the chart recording (Independent).

#### Remarks

#### Effects on setting parameters when changing a decimal location of the range

- You should set any parameter needs after setting the decimal location of the range. If you change the decimal location of the range after setting parameters, their values would be changed accordingly.
- If you change the decimal location of the range after changing the decimal location of the scale or chart recording, the latter would move to the same location as the former.

## 2. When entering the thermocouple/resistance thermometer

- (1) If you change the decimal location of the range (Example:0→1)

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-200	900	0	-200	900	0	0	-200	900	0

↓

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-20.0	90.0	1	-20.0	90.0	1	0.0	-20.0	90.0	1

The decimal locations of the scale, sensor correction, and chart recording are changed with a decimal location change of the range.

Type	Alarm Value	Dead Band	Type	Alarm Value	Dead Band
Upper	-32768	0	Upper	-3276.8	0.0

The decimal locations of the alarm value for the alarm setting and the dead band are also changed with a decimal location change of the range.

- (2) If you change the decimal location of the scale (Example:1→2)

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-20.0	90.0	1	-20.0	90.0	1	0.0	-20.0	90.0	1

↓

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-20.0	90.0	1	-20.00	90.00	2	0.00	-20.00	90.00	2

The decimal locations of the sensor correction and chart recording are changed with a decimal location change of the scale.

- (3) If you change the decimal location of the chart recording (Example:1→3)

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-20.0	90.0	1	-20.0	90.0	1	0.0	-20.0	90.0	1

↓

Range			Scale			Sensor	Chart Recording		
Lower	Upper	Decimal	Lower	Upper	Decimal		Lower	Upper	Decimal
-20.0	90.0	1	-20.0	90.0	1	0.0	-0.200	0.900	3

The decimal locations of the range, scale, and sensor correction are not changed with a decimal location change of the chart recording (Independent).

### Remarks → Effects on setting parameters when changing a decimal location of the range

- You should set any parameter needs after setting the decimal location of the range. If you change the decimal location of the range after setting parameters, their values would be changed accordingly.
- If you change the decimal location of the range after changing the decimal location of the scale or chart recording, the latter would move to the same location as the former.

## 6-1-4. Operation Flow

### <Procedure>

#### (1) Start this software

When you start the parameter setting software, the Parameter Setting Menu screen is displayed (refer to section 5-1).


#### (2) Select online or offline

Specify whether you set parameters of the software online or offline (see the table below). After the selection, click the [Parameter Setting] button to display the Parameter Setting screen.

##### [Select Online/Offline]

Selection item	Refer to
Offline (New)	Section 6-2-1
Offline (File)	Section 6-2-2
Online*	Section 6-2-3


- \* Check if the PC is connected to the instrument with an appropriate cable for the communication method.



#### (3) Create and obtain setting parameters

From the tool bar in the Parameter Setting screen, you can create new setting parameters, edit existing files, and communicate with the instrument to read setting parameters from it (refer to section 6-6).


Click the [New] button to create a new setting parameter, the [Open] button to edit an existing file, or the [Parameter Reading] button to communicate with the instrument to read setting parameters from it (refer to section 4).



#### (4) Edit in the Parameter Setting screen

The setting items and setting parameters of the instrument specified in the step 3 are displayed in the tree view and the edit panel in the Parameter Setting screen.


Select a setting item in the tree view and edit a setting parameter in the edit panel (refer to section 6-6-1 to 6-6-36).



## (5) Store and write setting parameters

Store the setting parameters that you edited to a file or write them to the connected instrument (refer to section 6-6).

From the tool bar in the Parameter Setting screen, click the [Save] button to save the setting parameters to a file or the [Parameter Writing] button to write to the connected instrument (refer to section 4).



## (6) Exit this software

Close the Parameter Setting screen, then close the Parameter Setting Menu screen (refer to section 5-2).

### Remarks → Precautions for Exit

When you edit setting parameters, click the [Save] button or the [Parameter Writing] button as appropriate before closing the Parameter Setting screen.

If you close the Parameter Setting screen without clicking the [Save] button or the [Parameter Writing] button after editing setting parameters, the data you entered would be lost.

## 6-1-5. Setting Items by Instrument

Setting items vary depending on the instrument (see the table below).

[Available items in the menu by the instrument] O: Available x: Unavailable △: Conditional

No.	Menu item	Available items by the instrument		Refer to
		AL4000/AH4000	KL4000/KH4000	
1	Range	○	○	Section 6-6-1
2	Alarm	○	○	Section 6-6-2
3	Calculation	○	○	Section 6-6-3
4	Calculation Formula	○	○	Section 6-6-4
5	Broken Line Approximation Table	○	○	Section 6-6-5
6	Chart Speed	○	○	Section 6-6-6
7	Analog Recording (Dot Printing Type)	○	○	Section 6-6-7
8	Subtract Printing	○	○	Section 6-6-8
9	Analog Recording (Trace Printing Interval)	○	x	Section 6-6-9
10	Periodic Data Printing	○	○	Section 6-6-10
11		○	○	Section 6-6-11
12	Message Printing 1	○	x	Section 6-6-12
13	Message Printing 2	○	x	Section 6-6-13
14	Recording Format	○	x	Section 6-6-14
15	Automatic Range Switching	○	x	Section 6-6-15
16	Compressed/Expanded Printing	○	x	Section 6-6-16
17	Zone Printing	○	x	Section 6-6-17
18	SD Card	○	x	Section 6-6-18
19	USB	○	○	Section 6-6-19
20	COM1	△(* 1)	△(* 1)	Section 6-6-20
21	COM2	△(* 1)	x	Section 6-6-21
22	Ethernet	△(* 1)	x	Section 6-6-22
23	SNTP	△(* 1)	x	Section 6-6-23
24	Email Address (Account)	△(* 1)	x	Section 6-6-24
25	Email Address (Destination)	△(* 1)	x	Section 6-6-25
26	Email Address (Sending Condition)	△(* 1)	x	Section 6-6-26
27	Calendar Timer	○	x	Section 6-6-27
28	External Drive	△(* 2)	△(* 2)	Section 6-6-28
29	Operation Recording	△(* 2)	x	Section 6-6-29
30	Failout	○	○	Section 6-6-30
31	Display	○	x	Section 6-6-31
32	Date/Time	△(* 3)	△(* 3)	Section 6-6-32
33	System	○	○	Section 6-6-33
34	Format	○	○	Section 6-6-34
35	Display Order	○	x	Section 6-6-35
36	Soft Dip Switch	○	○	Section 6-6-36

\* 1: Refer to the table "Available items in the menu by the communication method of the instrument."

\* 2: Refer to the table "Available items in the menu by the alarm output and the external drive method of the instrument."

\* 3: Not displayed when in offline.

\*1: [Available items in the menu by the communication method of the instrument] O: Available ×: Non-display

No.	Menu item	Available items by the communication method										Refer to	
		AL4000/AH4000						KL4000/KH4000					
		N	R	A	Q	C	G	N	R	A			
20	COM1	×	O	O	O	O	O	×	O	O		Section 6-6-20	
21	COM2	×	×	×	O	O	O	×	×	×		Section 6-6-21	
22	Ethernet	×	×	×	×	×	O	×	×	×		Section 6-6-22	
23	SNTP	×	×	×	×	×	O	×	×	×		Section 6-6-23	
24	Email Address (Account)	×	×	×	×	×	O	×	×	×		Section 6-6-24	
25	Email Address (Destination)	×	×	×	×	×	O	×	×	×		Section 6-6-25	
26	Email Address (Sending Condition)	×	×	×	×	×	O	×	×	×		Section 6-6-26	

N: None

R: RS-232C

A: RS-422A/RS-485

Q: RS-232C+RS-485

C: RS-422A/RS-485+RS-485

G: Ethernet + RS-422A/RS-485 + RS-485

\*2: [Available items in the menu by the alarm output and the external drive method of the instrument]

O: Available ×: Non-display

No.	Menu item	Available items by the alarm output and the external drive method												Refer to			
		AL4000/AH4000						KL4000/KH4000									
		0	2	4	A	8	B	F	D	0	2	4	A	8	B	F	D
28	External Drive	×	×	O	O	O	O	O	O	×	×	O	O	O	O	O	Section 6-6-28
29	Operation Recording	×	×	O	O	O	O	O	O	×	×	×	×	×	×	×	Section 6-6-29

0: None

2: Mechanical relay "a" contact alarm output 2 points

4: Mechanical relay "c" contact alarm output 4 points + external drive 5 points

A: Mechanical relay "a" contact alarm output 6 points + external drive 5 points

8: Mechanical relay "c" contact alarm output 8 points + external drive 10 points

B: Mechanical relay "a" contact alarm output 12 points + external drive 10 points

F: Mechanical relay "c" contact alarm output 16 points + external drive 20 points

D: Mechanical relay "a" contact alarm output 24 points + external drive 20 points

## 6-2. Operation of Parameter Setting Menu Screen

In the Parameter Setting Menu screen, specify whether you edit parameters of this software online or offline. There are three options to select online or offline.


Selection item	Description	Refer to
Offline (New)	Specify this option if you want to create parameters in a new file without communication.	Section 6-2-1
Offline (File)	Specify this option if you want to edit parameters in an existing file without communication.	Section 6-2-2
Online	Specify this option to edit parameters of the instrument through communication.	Section 6-2-3

\* You can also show the Help screen or the version from this menu screen (refer to section 6-7 and 6-8).

### 6-2-1. Offline (New) Setting

Specify this option if you want to create parameters in a new file without communication.

#### <Procedure>



**(1) Select [Offline (New)]**

Select [Offline (New)] from [Select Online/Offline].

**(2) Enter the format**

In [Format], enter the model of the instrument by using one byte characters excluding "- (hyphen)".

**(3) Click the [Parameter Setting] button**

Click the [Parameter Setting] button to display the Parameter Setting screen, where you can set parameters (refer to section 6-6).


**Remarks** If a warning message is displayed

Close the warning message window by clicking the [OK] button and reconfigure the model.

## 6-2-2. Offline (File) Setting

Specify this option if you want to edit parameters in an existing file without communication.

### <Procedure>




#### (1) Select [Offline (File)]

Select [Offline (File)] from [Select Online/Offline].

#### (2) Click the [Parameter Setting] button

The Open screen is displayed. Specify a file and click the [Open] button. The Parameter Setting screen is displayed to enable you to edit the specified file (refer to section 6-6).



#### Remarks


#### If a warning message is displayed

Close the warning message window by clicking the [OK] button and reconfigure the file.

### 6-2-3. Online Setting

Specify this option to edit parameters of the instrument through communication.

#### <Procedure>



**(1) Select [Online]**

Select [Online] from [Select Online/Offline].

\* Check if the PC is connected to the instrument with an appropriate cable for the communication method.

**(2) Select [Select Communication]**

Select a communication path for this software to communicate with the instrument from the [Select Communication] list.

Selection item
Ethernet
Serial
USB

**(3) Click the [Setting] button**

Click the [Set] button to display the setting screen for the communication path specified in the [Select Communication] list.

Select Communication	display screen	Refer to
When [Ethernet] is selected	Ethernet adapter setting screen	Refer to section 6-3
When [Serial] is selected	Serial adapter setting screen	Refer to section 6-4
When [USB] is selected	USB adapter setting screen	Refer to section 6-5

**(4) Click the [Parameter Setting] button**

Click the [Parameter Setting] button to display the Parameter Setting screen, where you can edit parameters for the connected instrument (refer to section 6-6).

**Remarks**


If a warning message is displayed

Close the message window by clicking the [OK] button in the warning message screen and reconfigure parameters after confirming there is no problem with the communication.

### 6-3. Operation of Ethernet Adapter Setting Screen

Configure the communication adapter for connecting PC to the instrument using Ethernet.  
This screen is displayed when you select [Online] and [Ethernet] from the [Select Communication] list in the Parameter Setting Menu screen.

#### <Procedure>



##### (1) Enter the IP address

Enter the IP address of the connected instrument using one byte characters.

Setting Range
"0.0.0.0" to "255.255.255.255"

DHCP (obtaining an IP address automatically) cannot be used.

For the IP address, please contact the network administrator of the network you are connecting to.

##### (2) Enter the port number

Enter the port number.

Setting Range
0 to 65535

##### (3) Click the [OK] button

Click the [OK] button to close the Ethernet adaptor setting screen.


Return to the Parameter Setting Menu screen and continue your setting (refer to (4) in section 6-2-3).

## 6-4. Operation of Serial Adapter Setting Screen

Configure the communication adapter for connecting PC to the instrument using serial.

This screen is displayed when you select [Online] and [Serial] from the [Select Communication] list in the Parameter Setting Menu screen.

### <Procedure>



#### (1) Configure MODBUS

Specify the address and the communications protocol with the connected instrument.

Programming parameter	Setting Range
Address	1 to 99
Protocol	MODBUS (RTU) MODBUS (ASCII)

#### (2) Configure the serial communication

Configure the serial communication.

Programming parameter	Setting Range
Port	Displays the serial port name options obtained from the PC. * This field is blank if serial port names cannot be obtained.
Speed	4800
	9600
	19200
	38400
Data bit	7
	8

Programming parameter	Setting Range
Parity	None
	Odd
Stop Bit	Even
	1
	2

#### (3) Click the [OK] button

Click the [OK] button to close the serial adaptor setting screen.


Return to the Parameter Setting Menu screen and continue your setting (refer to (4) in section 6-2-3).

## 6-5. Operation of USB Adapter Setting Screen

Configure the communication adapter for connecting PC to the instrument using USB.

This screen is displayed when you select [Online] and [USB] from the [Select Communication] list in the Parameter Setting Menu screen.

### <Procedure>



#### (1) Enter the identification ID

Enter the identification ID using one byte characters.

Setting Range
1 to 5

#### (2) Click the [OK] button

Click the [OK] button to close the USB adaptor setting screen.

Return to the Parameter Setting Menu screen and continue your setting (refer to (4) in section 6-2-3).

## 6-6. Operation of Parameter Setting Screen


The Parameter Setting screen consists of the tool bar, tree view, and edit panel.

The tool bar allows you to create and store a file and perform external input/output of parameters, the tree view to select setting items for obtained parameters, and the edit panel to edit setting parameter values.

### Remarks

When you edit setting parameters, click the [Save] button or the [Parameter Writing] button as appropriate before closing the Parameter Setting screen.

If you close the Parameter Setting screen without clicking the [Save] button or the [Parameter Writing] button after editing setting parameters, the data you entered would be lost.



Display Configuration	Description
Tool bar	<p>From the tool bar, you can operate the files, read and write parameters, and show the Help page. Instrument information obtained from the tool bar is displayed in the tree view and the edit panel.</p> <p>Buttons on the tool bar are enabled or disabled depending on whether you select online or offline. When buttons are enabled, they are displayed in color and can be clicked. When buttons are disabled, they are displayed in gray and cannot be clicked (refer to the table in the next page).</p>
Tree view	<p>In the tree view, instrument information obtained from the tool bar is displayed by category (setting item). When you select a setting item displayed in the tree view, its setting parameter is displayed in the edit panel.</p> <p>The setting items displayed in the tree view vary depending on the instrument model to be edited (refer to section 6-1-5).</p>
Edit panel	<p>In the edit panel, the setting parameters of the setting item selected in the tree view are displayed. You can select a setting parameter displayed in the edit panel to edit its value.</p>

[Buttons on the tool bar and their availability]

O: Enabled x: Disabled

Button		Description	Enabled/Disabled when selecting		
			Offline (New)	Offline (File)	Online
	New	Creates a new setting file. The edit panel is updated with the initial values.	O	O	x
	Open	Reads a specified setting file and displays its parameters in the edit panel.	O	O	O
	Save	Overwrites the setting file when it exists or stores the file with a new name in any folder when the specified file does not exist.	O	O	O
	Copy	Duplicates parameters and holds them temporarily (see the table below). The duplicated parameters are kept after a paste operation and will be updated when this button is clicked the next time.	O (* 1)	O (* 1)	O (* 1)
	Paste	Pastes the parameters duplicated by the [Copy] button (see the table below).	O (* 2)	O (* 2)	O (* 2)
	Parameter Reading	Reads parameters from the connected instrument through communication (refer to section 4) and displays them in the tree view and the edit panel.	x	x	O
	Parameter Writing	Writes the edited parameters to the connected instrument through communication (refer to section 4).	x	x	O
	Help	Shows the help information. You can see the help (refer to section 6-7) and version information (refer to section 6-8).	O	O	O

\* 1: Enabled only when the [Copy] button is available in the displayed edit panel.


\* 2: Enabled only when parameters are duplicated by the [Copy] button.

[Edit panels in which the [Copy] and [Paste] buttons are available and a set of parameters to be duplicated]

Edit panel	A set of parameters to be duplicated	Refer to
Range	Parameters belonging to one CH	2. in section 6-6-1
Alarm	Parameters belonging to one alarm level	2. in section 6-6-2
Calculation	Parameters belonging to one CH	2. in section 6-6-3
Calculation Formula	Parameters belonging to one calculation formula number	2. in section 6-6-4
Broken Line Approximation Table	Parameters belonging to one table	2. in section 6-6-5
Subtract Printing	Parameters belonging to one CH	2. in section 6-6-8
Periodic Data Printing (Specified Time)	Parameters belonging to one specified time number	2. in section 6-6-11
Message Printing 1	Parameters belonging to one message number	2. in section 6-6-12
Automatic Range Switching	Parameters belonging to one CH	2. in section 6-6-15
Compressed/Expanded Printing	Parameters belonging to one CH	2. in section 6-6-16
Calendar Timer	Parameters belonging to one timer number	2. in section 6-6-27
Operation Recording	Parameters belonging to one external drive number	2. in section 6-6-29

## 6-6-1. Range Settings "Range"

- The range settings for the input channel are displayed in the table format to enable you to edit them.
  - The columns of the table present the setting parameter types, and the rows present the channel numbers.
  - For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.
  - The number of the displayed channels vary depending on the instrument model.
- \* Refer to the instruction manual of the instrument and other manuals for more details on the settings.



### 1. Parameter setting

For the range settings, you can edit the following setting parameters by the channel.

#### [Range Settings "Range" Parameter List]

Setting parameter	Function	Remarks								
Input Type "INPUT"	Select the input type	<b>For AL4000/AH4000</b> * 1: Refer to the table "[Input type for AL4000/AH4000]" <b>For KL4000/KH4000</b> * 2: Refer to the table "[Input type for KL4000/KH4000]"								
RJ "RJ"	Select whether the reference junction compensation contact is used or not <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Internal</td> <td>INT</td> </tr> <tr> <td>External</td> <td>EXT</td> </tr> </table>	Software screen	Instrument screen	Internal	INT	External	EXT	If you change the input type to [Unused], [DC voltage], or [Resistance thermometer], for which you cannot set whether RJ is used or not, the [RJ] setting is changed to [External].		
Software screen	Instrument screen									
Internal	INT									
External	EXT									
Burnout "BURN"	Select whether the burn is detected or not and the operation if detected <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>None</td> <td>None</td> </tr> <tr> <td>Up</td> <td>UP</td> </tr> <tr> <td>Down</td> <td>DOWN</td> </tr> </table>	Software screen	Instrument screen	None	None	Up	UP	Down	DOWN	If you change the input type to [Unused] or the DC voltage more than $\pm 69\text{mV}$ , for which you cannot set the burnout, the [Burnout] setting is changed to [None].
Software screen	Instrument screen									
None	None									
Up	UP									
Down	DOWN									
Decimal Location	Set the decimal location	Refer to section 6-1								
Scale Minimum "RANGE-L"	The minimum value of the measurement range to be used in the range that is determined by the input type	-30000 to 30000 It can be set to three places of decimals. Example: -30.000								
Scale Maximum "RANGE-H"	The maximum value of the measurement range to be used in the range that is determined by the input type	The decimal location changes according to the one of the range An overflow value is displayed as "#####"								
Scale Lower Limit "SCALE-L"	The minimum value to be used for scaling for the range determined by the range minimum and maximum values when the voltage range such as mV is selected as the input type	-30000 to 99999 It can be set to three places of decimals. Example: -30.000 The decimal location changes according to the one of the scale								
Scale Upper Limit "SCALE-H"	The maximum value to be used for scaling for the range determined by the range minimum and maximum values when the voltage range such as mV is selected as the input type	When online, an overflow value is displayed as "#####"								

Sensor Correction "SHIFT"	The offset amount for the data after scaling	-30000 to 99999 See the remarks of "Scale Lower/Upper Limit" for details						
Chart Recording Lower Limit "REC-L"	The minimum value (Left) of the chart recording	-30000 to 99999 It can be set to three places of decimals. Example: -30.000 The decimal location changes according to the one of the chart recording						
Chart Recording Upper Limit "REC-H"	The maximum value (Right) of the chart recording	When online, an overflow value is displayed as "#####"						
Unit "UNIT"	Set the number of characters using up to 6 characters	Available characters (one byte): ABCDEFGHIJKLMNOPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz 0123456789+/*%^()_.;,>=!=![]¥ (refer to section 6-1-2)						
Display "Disp"	Select whether the measurement value is displayed or not <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>Display</td><td>ON</td></tr><tr><td>Hide</td><td>OFF</td></tr></table>	Software screen	Instrument screen	Display	ON	Hide	OFF	
Software screen	Instrument screen							
Display	ON							
Hide	OFF							
Analog Recording "Rec"	Specify whether the analog recording is turned on or off <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>Record</td><td>ON</td></tr><tr><td>Do Not Record</td><td>OFF</td></tr></table>	Software screen	Instrument screen	Record	ON	Do Not Record	OFF	
Software screen	Instrument screen							
Record	ON							
Do Not Record	OFF							
Digital Recording/Printing "DIGI.REC"	Select the digital recording/printing is turned on or off <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>Record</td><td>ON</td></tr><tr><td>Do Not Record</td><td>OFF</td></tr></table>	Software screen	Instrument screen	Record	ON	Do Not Record	OFF	
Software screen	Instrument screen							
Record	ON							
Do Not Record	OFF							
SD Card Recording "SD-CARD.REC"	Specify whether the SD card recording is turned on or off <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>Record</td><td>ON</td></tr><tr><td>Do Not Record</td><td>OFF</td></tr></table>	Software screen	Instrument screen	Record	ON	Do Not Record	OFF	
Software screen	Instrument screen							
Record	ON							
Do Not Record	OFF							

#### \*1: [Input type for AL4000/AH4000]

Input type (Initial value)	Input type (Initial value)	Input type (Initial value)	Input type (Initial value)
Unused	25: E (-200.0 to 350.0)	51: U (-200.0 to 250.0)	47: CR-AuFe (0.0 to 280.0)
01: mV (-13.80 to 13.80)	26: E (-200 to 900)	52: U (-200.0 to 500.0)	94: Au/Pt (0.0 to 1000.0)
02: mV (-27.60 to 27.60)	27: J (-200.0 to 250.0)	53: U (-200.0 to 600.0)	70: Pt100 (-140.0 to 150.0)
03: mV (-69.00 to 69.00)	28: J (-200.0 to 500.0)	54: L (-200.0 to 250.0)	71: Pt100 (-200.0 to 300.0)
04: mV (-200.0 to 200.0)	29: J (-200 to 1200)	55: L (-200.0 to 500.0)	84: Pt100 (-200.0 to 649.0)
05: mV (-500.0 to 500.0)	30: T (-200.0 to 250.0)	56: L (-200 to 900)	72: Pt100 (-200.0 to 850.0)
16: V (-1.00 to 1.00)	31: T (-200.0 to 400.0)	40: W-WRe26 (0 to 2315)	73: oPt100 (-140.0 to 150.0)
07: V (-5.00 to 5.00)	32: R (0 to 1200)	41: WRe5-WRe26(0 to 2315)	74: oPt100 (-200.0 to 300.0)
08: V (-10.00 to 10.00)	33: R (0 to 1760)	44: NiMo-Ni (0.0 to 290.0)	75: oPt100 (-200.0 to 649.0)
09: V (-20.00 to 20.00)	34: S (0 to 1300)	45: NiMo-Ni (0.0 to 600.0)	76: JPt100 (-140.0 to 150.0)
10: V (-50.00 to 50.00)	35: S (0 to 1760)	46: NiMo-Ni (0 to 1310)	77: JPt100 (-200.0 to 300.0)
21: K (-200.0 to 300.0)	36: B (0 to 1820)	48: Platinel2 (0.0 to 350.0)	78: JPt100 (-200.0 to 649.0)
22: K (-200.0 to 600.0)	37: N (-200.0 to 400.0)	49: Platinel2 (0.0 to 650.0)	79: Pt50 (-200.0 to 649.0)
23: K (-200 to 1370)	38: N (-200.0 to 750.0)	50: Platinel2 (0 to 1390)	80: Pt-Co (4.0 to 374.0)
24: E (-200.0 to 200.0)	39: N (-200 to 1300)	43: PtRh40-20 (0 to 1880)	
	40: N (-200 to 1300)	51: Pt100 (-200.0 to 250.0)	
	41: N (-200 to 1300)	52: Pt100 (-200.0 to 500.0)	
	42: N (-200 to 1300)	53: Pt100 (-200.0 to 600.0)	

#### \*2: [Input type for KL4000/KH4000]

Input type (Initial value)	Input type (Initial value)	Input type (Initial value)	Input type (Initial value)
Unused	29: J (-200 to 1200)	68: L (-150.0 to 120.0)	71: Pt100 (-200.0 to 300.0)
13: mV (-6.900 to 6.900)	63: T (-150.0 to 150.0)	55: L (-200.0 to 500.0)	84: Pt100 (-200.0 to 649.0)
01: mV (-13.80 to 13.80)	30: T (-200.0 to 250.0)	56: L (-200 to 900)	95: oPt100 (-50.0 to 50.0)
02: mV (-27.60 to 27.60)	31: T (-200.0 to 400.0)	40: W-WRe26 (0 to 2315)	88: oPt100 (-100.0 to 100.0)
03: mV (-69.00 to 69.00)	33: R (0 to 1760)	41: WRe5-WRe26(0 to 2315)	73: oPt100 (-140.0 to 150.0)
15: mV (-100.0 to 100.0)	35: S (0 to 1760)	46: NiMo-Ni (0 to 1310)	74: oPt100 (-200.0 to 300.0)
06: V (-2.00 to 2.00)	36: B (0 to 1820)	66: Platinel2 (0.0 to 150.0)	75: oPt100 (-200.0 to 649.0)
07: V (-5.00 to 5.00)	64: N (-200.0 to 200.0)	48: Platinel2 (0.0 to 350.0)	92: JPt100 (-50.0 to 50.0)
65: K (-150.0 to 150.0)	37: N (-200.0 to 400.0)	49: Platinel2 (0.0 to 650.0)	93: JPt100 (-100.0 to 100.0)
21: K (-200.0 to 300.0)	38: N (-200.0 to 750.0)	50: Platinel2 (0 to 1390)	76: JPt100 (-140.0 to 150.0)
22: K (-200.0 to 600.0)	39: N (-200 to 1300)	43: PtRh40-20 (0 to 1880)	77: JPt100 (-200.0 to 300.0)
23: K (-200 to 1370)	67: U (-150.0 to 150.0)	47: CR-AuFe (0.0 to 280.0)	78: JPt100 (-200.0 to 649.0)
25: E (-200.0 to 350.0)	51: U (-200.0 to 250.0)	69: Pt100 (-50.0 to 50.0)	79: Pt50 (-200.0 to 649.0)
26: E (-200 to 900)	52: U (-200.0 to 500.0)	81: Pt100 (-100.0 to 100.0)	80: Pt-Co (4.0 to 374.0)
28: J (-200.0 to 500.0)	53: U (-200.0 to 600.0)	70: Pt100 (-140.0 to 150.0)	

## 2. Copy and paste operations for range setting


For the range setting, you can copy and paste parameters per one channel (parameters belonging to one channel).

### <How to copy/paste>

#### (1) Select the copy source


Click to select a channel number or any column to copy from.

- \* You can copy parameters per one channel. That means, you cannot select multiple channels to copy the parameters at a time.



#### (2) Click the [Copy] button


Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


Click to select a channel number or any column to paste to.

- \* You can paste the parameters to one channel. That means, you cannot select multiple channels to paste the parameters at a time.



#### (4) Click the [Paste] button

Click the [Paste] button from the tool bar to paste the parameters to the selected location.



#### Remarks > "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one channel.


#### Remarks > Effects on other settings

Changing the input type, scale upper limit, or scale lower limit in the range setting can affect other settings such as the alarm, dead band, and so on.

This applies to the copy operation. Please pay attention.

## 6-6-2. Alarm Settings "Alarm"

- The alarm settings for the alarm channels are displayed in the table format to enable you to edit them.
  - The columns of the table present the setting parameter types, and the rows present the pairs of the channel number and the alarm level.
  - For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.
  - The number of the displayed channels varies depending on the instrument model.
- \* Refer to the instruction manual of the instrument for more details on the settings.



Move the scroll bar to the right  
to display hidden setting parameters.

### 1. Parameter setting

For the alarm settings, you can edit the following setting parameters by the level of the channel.

#### [Alarm Settings "Alarm" Parameter List]

Setting parameter	Function	Remarks																
Level "Level"	Select the setting level <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>Level1</td><td>(Level) 1</td></tr> <tr><td>Level2</td><td>(Level) 2</td></tr> <tr><td>Level 3*</td><td>(Level) 3 *</td></tr> <tr><td>Level 4*</td><td>(Level) 4 *</td></tr> </table>	Software screen	Instrument screen	Level1	(Level) 1	Level2	(Level) 2	Level 3*	(Level) 3 *	Level 4*	(Level) 4 *							
Software screen	Instrument screen																	
Level1	(Level) 1																	
Level2	(Level) 2																	
Level 3*	(Level) 3 *																	
Level 4*	(Level) 4 *																	
Type "Mode"	Select the alarm type <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>None</td></tr> <tr><td>Upper</td><td>H</td></tr> <tr><td>Lower</td><td>L</td></tr> <tr><td>Rate-of-Change Upper</td><td>U</td></tr> <tr><td>Rate-of-Change Lower</td><td>D</td></tr> <tr><td>Diff. Upper</td><td>B</td></tr> <tr><td>Diff. Lower</td><td>S</td></tr> </table>	Software screen	Instrument screen	None	None	Upper	H	Lower	L	Rate-of-Change Upper	U	Rate-of-Change Lower	D	Diff. Upper	B	Diff. Lower	S	
Software screen	Instrument screen																	
None	None																	
Upper	H																	
Lower	L																	
Rate-of-Change Upper	U																	
Rate-of-Change Lower	D																	
Diff. Upper	B																	
Diff. Lower	S																	

Alarm Value "Value"	Specify the alarm judgment value * Displays "None" only in KL4000/KH4000	-30000 to 99999 The decimal location changes according to the one of the scale When online, an overflow value is displayed as "#####"								
Dead Band "D.Band"	Setting the dead band width	0 to 99999 See the remarks of "Alarm Value" for details								
Comparison CH "Comp.CH"	Specify the channel (standard CH) to be subtracted from the setting channel (Only for the differential alarm)	The number of the displayed channels vary depending on the instrument model.								
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>1 to 24</td><td>1 to 24</td></tr> </table>	Software screen	Instrument screen	1 to 24	1 to 24					
Software screen	Instrument screen									
1 to 24	1 to 24									
Rate-of-Change Standard Time (sec.) "Std.TIME"	Specify the rate-of-change standard time (Only for the rate-of-change alarm)	The minimum setting unit is 1 second								
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>0 to 6000</td><td>0 to 6000</td></tr> </table>	Software screen	Instrument screen	0 to 6000	0 to 6000					
Software screen	Instrument screen									
0 to 6000	0 to 6000									
Delay (sec.) "Delay"	Specify the delay time from an alarm decision to the output	The minimum setting unit is 1 second								
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>0 to 6000</td><td>0 to 6000</td></tr> </table>	Software screen	Instrument screen	0 to 6000	0 to 6000					
Software screen	Instrument screen									
0 to 6000	0 to 6000									
Output No. "Relay No."	Specify the location to which an alarm is output (relay number)	The number of the displayed channels vary depending on the instrument model.								
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 24</td><td>1 to 24</td></tr> <tr><td>Dummy Output</td><td>99</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 24	1 to 24	Dummy Output	99	
Software screen	Instrument screen									
None	-									
1 to 24	1 to 24									
Dummy Output	99									
Output Mode "And/Or"	Select the connection method for connecting to the output destination									
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>OR</td><td>Or</td></tr> <tr><td>AND</td><td>And</td></tr> </table>	Software screen	Instrument screen	OR	Or	AND	And			
Software screen	Instrument screen									
OR	Or									
AND	And									
Trigger Message No. "Message No Activation"	Specify the message No. to be printed when an alarm occurs									
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 20</td><td>1 to 20</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 20	1 to 20			
Software screen	Instrument screen									
None	-									
1 to 20	1 to 20									
Cancel Message No. "Message No Reset"	Specify the message No. to be printed when an alarm is reset									
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 20</td><td>1 to 20</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 20	1 to 20			
Software screen	Instrument screen									
None	-									
1 to 20	1 to 20									
Display Stored "Hold-DISP"	Select whether the alarm display and the Status LED "ALM" are stored or not									
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>Stop</td><td>Not Hold</td></tr> <tr><td>Cancel By Key Operation</td><td>Hold:Reset by KEY</td></tr> <tr><td>Cancel By External Drive</td><td>Hold:Reset by EX</td></tr> </table>	Software screen	Instrument screen	Stop	Not Hold	Cancel By Key Operation	Hold:Reset by KEY	Cancel By External Drive	Hold:Reset by EX	
Software screen	Instrument screen									
Stop	Not Hold									
Cancel By Key Operation	Hold:Reset by KEY									
Cancel By External Drive	Hold:Reset by EX									
Maintain Output "Hold-OUT"	Select whether the alarm output status is maintained or not									
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>Stop</td><td>Not Hold</td></tr> <tr><td>Cancel By Key Operation</td><td>Hold:Reset by KEY</td></tr> <tr><td>Cancel By External Drive</td><td>Hold:Reset by EX</td></tr> </table>	Software screen	Instrument screen	Stop	Not Hold	Cancel By Key Operation	Hold:Reset by KEY	Cancel By External Drive	Hold:Reset by EX	
Software screen	Instrument screen									
Stop	Not Hold									
Cancel By Key Operation	Hold:Reset by KEY									
Cancel By External Drive	Hold:Reset by EX									
Cancel External Drive No. "Hold-EX"	Specify the linking external drive No. when [Hold:Reset by EX] is selected in [Hold-OUT]	If the alarm status is "reset", the maintained output status is canceled when you switch the external drive No. specified here from OFF to ON The number of the displayed channels vary depending on the instrument model.								
	<table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 20</td><td>1 to 20</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 20	1 to 20			
Software screen	Instrument screen									
None	-									
1 to 20	1 to 20									

**Remarks** Relation with the decimal location in the scale setting value

The decimal locations of the alarm value and dead band are changed according to the one of the scale setting value for the setting channel. If you change the decimal location of the scale in Range settings, the ones of the alarm value and dead band are changed accordingly. The dead band is specified with an absolute value.

## 2. Copy and paste operations for alarm setting


For the alarm setting, you can copy and paste parameters per level (parameters belonging to one alarm level).

### <How to copy/paste>

#### (1) Select the copy source


Click to select a level or any column to copy from.

- \* You can copy parameters per one level. That means, you cannot select multiple levels to copy the parameters at a time.



#### (2) Click the [Copy] button


Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


Click to select a level or any column to paste to.

- \* You can paste the parameters to one level. That means, you cannot select multiple levels to paste the parameters at a time.



#### (4) Click the [Paste] button

Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one level.

### 6-6-3. Calculation Settings "Calc"

- The calculation settings for the input channel are displayed in the table format to enable you to edit them.
- The columns of the table present the setting parameter types, and the rows present the channel numbers.
- When you select [Calculation Formula] in [Calculation Type], you need to perform the Calculation Formula Settings (refer to section 6-4-4). When you select [Broken Line Approximation], you need to perform the Broken Line Approximation Table Settings (refer to section 6-6-5).
 

\* Refer to the instruction manual of the instrument for more details on the settings.
- For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.
- The number of the displayed channels vary depending on the instrument model.



Move the scroll bar to the right  
to display hidden setting parameters.

#### 1. Parameter setting

For the calculation settings, you can edit the following setting parameters by the channel.

##### [Calculation Settings "Calc" Parameter List]

Setting parameter	Function		Remarks
Calculation Type "Kind"	Select the calculation type		
	Software screen	Instrument screen	
	None	None	
	Square Roots Calculation	Root	
	Natural Logarithmic Calculation	LoGe	
	Common Logarithmic Calculation	LOG10	
	Integration Calculation	INT	
	Temperature/Humidity Calculation	Humidity	
	Data Communication Input	COM.Input	
	Arithmetic Calculation 1(MUL)	MUL	
	Arithmetic Calculation 2(DIV)	DIV	
	Maximum Value Calculation	High-Peak	
	Minimum Value Calculation	Low-Peak	
	Average Calculation	Average	
	Exponential Calculation	Power	
	Calculation Formula	Formula	
	Broken Line Approximation	BrokenLine	

Calculation Formula No. "Form.No."	When you select [Calculation Formula] in [Calculation Type], specify the calculation formula No. to use <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 12</td><td>1 to 12</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 12	1 to 12					
Software screen	Instrument screen											
None	-											
1 to 12	1 to 12											
Broken Line Table No. "Seg.Table No."	When you select [Broken Line Approximation] in [Calculation Type], specify the broken line table No. to use <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 6</td><td>1 to 6</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 6	1 to 6					
Software screen	Instrument screen											
None	-											
1 to 6	1 to 6											
Calculation Result Decimal Location "Decimal point"	Specify the decimal location in the calculation result <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>0 to 3</td><td>0 to 3</td></tr> </table>	Software screen	Instrument screen	0 to 3	0 to 3							
Software screen	Instrument screen											
0 to 3	0 to 3											
Calculation Target CH X "CH.X"	Specify the CH for the target X data to be used in calculations <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 24</td><td>1 to 24</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 24	1 to 24	The number of the displayed channels varies depending on the instrument model.				
Software screen	Instrument screen											
None	-											
1 to 24	1 to 24											
Calculation Target CH Y "CH.Y"	Specify the CH for the target Y data to be used in calculations <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 24</td><td>1 to 24</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 24	1 to 24	The number of the displayed channels varies depending on the instrument model.				
Software screen	Instrument screen											
None	-											
1 to 24	1 to 24											
Decimal Location	Specify the decimal location in the calculation constant A - D	It can be set to three places of decimals. Example: -30.000										
Calculation Constant A "Const.A"	When you select [Arithmetic Calculation 1(MUL)] and [Arithmetic Calculation 2(DIV)] in [Calculation Type], specify [Calculation Constant A]	-30000 to 99999 This changes according to the decimal location of each calculation constant value										
Calculation Constant B "Const.B"	When you select [Arithmetic Calculation 1(MUL)] and [Arithmetic Calculation 2(DIV)] in [Calculation Type], specify [Calculation Constant B]	It can be set to three places of decimals. Example: -30.000 When online, an overflow value is displayed as "#####"										
Calculation Constant C "Const.C"	When you select [Arithmetic Calculation 1(MUL)] in [Calculation Type], specify [Calculation Constant C]											
Calculation Constant D "Const.D"	When you select [Arithmetic Calculation 1(MUL)] in [Calculation Type], specify [Calculation Constant D]											
Start Time (Hour, Minute) "[Start]"	Specify the calculation start time After setting this value, the calculation is postponed until the specified start time (Until then, the data is invalid) <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>0*: 00 to 23*: 59</td><td>0*: 00 to 23*: 59</td></tr> </table> **- can be set as the "hour" in the time	Software screen	Instrument screen	0*: 00 to 23*: 59	0*: 00 to 23*: 59	If "-" is set, the calculation starts as follows: <b>Integration:</b> Starts by the external reset <b>Maximum value, Minimum value, Average, Calculation formula:</b> Starts when the power is turned on or immediately after setting this value						
Software screen	Instrument screen											
0*: 00 to 23*: 59	0*: 00 to 23*: 59											
Interval (Hour, Minutes) "[Interval]"	Specify the calculation interval When an integration operation is specified, the integrated value is reset with this interval <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>0*: 00 to 24*: 59</td><td>0*: 00 to 24*: 59</td></tr> </table> **- can be set as the "hour" in the time	Software screen	Instrument screen	0*: 00 to 24*: 59	0*: 00 to 24*: 59	If "-" is set, the interval is invalid.						
Software screen	Instrument screen											
0*: 00 to 24*: 59	0*: 00 to 24*: 59											
Time Unit "TimeUnit"	Integration time unit <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>Hour</td><td>Hour</td></tr> <tr><td>Minute</td><td>Min</td></tr> <tr><td>Second</td><td>Sec</td></tr> </table>	Software screen	Instrument screen	Hour	Hour	Minute	Min	Second	Sec			
Software screen	Instrument screen											
Hour	Hour											
Minute	Min											
Second	Sec											
Reset Method "INT-Reset"	Specify the method to reset the integrated value from an integration operation <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>None</td><td>None</td></tr> <tr><td>Interval</td><td>Interval</td></tr> <tr><td>External Drive (Batch)</td><td>EX (All)</td></tr> <tr><td>External Drive (Individual)</td><td>EX</td></tr> </table>	Software screen	Instrument screen	None	None	Interval	Interval	External Drive (Batch)	EX (All)	External Drive (Individual)	EX	
Software screen	Instrument screen											
None	None											
Interval	Interval											
External Drive (Batch)	EX (All)											
External Drive (Individual)	EX											
External Drive No. "INT-Reset.EX"	If you select [External Drive (Batch)] or [External Drive (Individual)] in [Reset Method], specify the linking external drive No. <table border="1"> <tr><th>Software screen</th><th>Instrument screen</th></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 20</td><td>1 to 20</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 20	1 to 20	The number vary depending on the instrument model.				
Software screen	Instrument screen											
None	-											
1 to 20	1 to 20											

## 2. Copy and paste operations for calculation setting


For the calculation setting, you can copy and paste parameters per channel (parameters belonging to one channel).

### <How to copy/paste>

#### (1) Select the copy source


Click to select a channel number or any column to copy from.

- \* You can copy parameters per one channel. That means, you cannot select multiple channels to copy the parameters at a time.



#### (2) Click the [Copy] button


Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


Click to select a channel number or any column to paste to.

- \* You can paste the parameters to one channel. That means, you cannot select multiple channels to paste the parameters at a time.



#### (4) Click the [Paste] button

Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks → "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one channel.

## 6-6-4. Calculation Formula Settings "Formula"

- The settings for the calculation formula are displayed in the table format to enable you to edit them.
  - The columns of the table present the calculation formulas, and the rows present the calculation formula numbers.
  - You can use a registered calculation formula by selecting it in [Calculation Type] in the [Calculation] settings.
  - For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.
- \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the calculation formula settings.

#### [Calculation Formula Settings "Formula" Parameter List]

Setting parameter	Function	Remarks
Calculation Formula "Formula"	<p>Specify the calculation formula to be used when you set [Calculation Formula] in the [Calculation] settings, using 50 characters (one byte) at a maximum</p> <p>Up to 12 formulas can be registered, common to all channels</p>	<p>Available characters (one byte):</p> <p>ABCDEFGHIJKLMNOPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz 0123456789+-*/%^(),.&lt;&gt;=#! (refer to section 6-1-2)</p>

## 2. Copy and paste operations for calculation formula setting


For the calculation formula setting, you can copy and paste parameters per calculation formula (parameters belonging to one calculation formula number).

### <How to copy/paste>

#### (1) Select the copy source


Click to select a calculation formula number to copy from.

- \* You can copy parameters per one calculation formula number. That means, you cannot select multiple calculation formula numbers to copy the parameters at a time.



#### (2) Click the [Copy] button


Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


Click to select a calculation formula number to paste to.

- \* You can paste the parameters to one calculation formula number. That means, you cannot select multiple calculation formula numbers to paste the parameters at a time.



#### (4) Click the [Paste] button

Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks > "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one calculation formula number.

## 6-6-5. Broken Line Approximation Table Settings "Seg.Tbl"

- The settings for the broken line approximation table are displayed in the [Tables 1] to [Table 6] tabs to enable you to edit them.
- The columns of the table present the coefficient types, and the rows present the coefficient numbers. Specify the decimal location of each coefficient above the table.
- You can set 6 tables and 30 broken lines at a maximum per table. For each channel with [Broken Line Approximation] selected in [Calculation Type], select a table to use from these 6 tables.
- For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the broken line approximation table settings.

#### [Broken Line Approximation Table Settings "Seg.Tbl" Parameter List]

Setting parameter	Function	Remarks						
X Axis Coefficient Decimal Location "X.Dot"	Specify the X axis coefficient decimal location <table border="1" style="width: 100%;"><tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>0 to 3</td> <td>0 to 3</td> </tr> </table>	Software screen	Instrument screen	0 to 3	0 to 3	It can be set to three places of decimals. Example: -30.000		
Software screen	Instrument screen							
0 to 3	0 to 3							
Y Axis Coefficient Decimal Location "Y.Dot"	Specify the Y axis coefficient decimal location <table border="1" style="width: 100%;"><tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>0 to 3</td> <td>0 to 3</td> </tr> </table>	Software screen	Instrument screen	0 to 3	0 to 3	It can be set to three places of decimals. Example: -30.000		
Software screen	Instrument screen							
0 to 3	0 to 3							
X Axis Coefficient "X-01 to X-30"	Specify X1 - X30 in the broken line approximation table <table border="1" style="width: 100%;"><tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Disabled</td> <td>-</td> </tr> <tr> <td>-30000 to 99999</td> <td>-30000 to 99999</td> </tr> </table>	Software screen	Instrument screen	Disabled	-	-30000 to 99999	-30000 to 99999	When online, an overflow value is displayed as "#####"
Software screen	Instrument screen							
Disabled	-							
-30000 to 99999	-30000 to 99999							
Y Axis Coefficient "Y-01 to Y-30"	Specify Y1 - Y30 in the broken line approximation table <table border="1" style="width: 100%;"><tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Disabled</td> <td>-</td> </tr> <tr> <td>-30000 to 99999</td> <td>-30000 to 99999</td> </tr> </table>	Software screen	Instrument screen	Disabled	-	-30000 to 99999	-30000 to 99999	
Software screen	Instrument screen							
Disabled	-							
-30000 to 99999	-30000 to 99999							

## 2. Copy and paste operations for broken line approximation table setting


For the broken line approximation table setting, you can copy and paste parameters per table (parameters belonging to one table).

### <How to copy/paste>

#### (1) Select the copy source


Click to select a table to copy from.

- \* You can copy parameters per one table. That means, you cannot select multiple tables to copy the parameters at a time.



#### (2) Click the [Copy] button


Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


Click to select a table to paste to.

- \* You can paste the parameters to one table. That means, you cannot select multiple tables to paste the parameters at a time.



#### (4) Click the [Paste] button

Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one table.

## 6-6-6. Chart Speed Settings "Chart"

- The chart speed settings are displayed to enable you to edit them.
- The chart speed 1 to 3 are displayed. The left and right numbers present the integer and fraction parts respectively. The setting unit is mm/H. The value converted to mm/M is displayed in parentheses next to the chart speed display unit (mm/H).
- For AL4000/AH4000 and KL4000/KH4000, you can edit these settings. For AL4000/AH4000 without an external drive, you can set the value of the chart speed 1 only.

\* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the chart speed settings.

#### [Chart Speed Settings "Chart" Parameter List]

Setting parameter	Function	Remarks						
Chart Speed 1 "ChartSpeed1"	Configure the chart speed 1 <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>1 to 1500</td> <td>1 to 1500</td> </tr> <tr> <td>12.5 *</td> <td>12.5 *</td> </tr> </table>	Software screen	Instrument screen	1 to 1500	1 to 1500	12.5 *	12.5 *	* You can set 0 (12.0mm/H) or 5 (12.5mm/H) for the right fraction part when the left integer part is 12.
Software screen	Instrument screen							
1 to 1500	1 to 1500							
12.5 *	12.5 *							
Chart Speed 2 "ChartSpeed2"	Configure the chart speed 2 <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>1 to 1500</td> <td>1 to 1500</td> </tr> <tr> <td>12.5 *</td> <td>12.5 *</td> </tr> </table>	Software screen	Instrument screen	1 to 1500	1 to 1500	12.5 *	12.5 *	
Software screen	Instrument screen							
1 to 1500	1 to 1500							
12.5 *	12.5 *							
Chart Speed 3 "ChartSpeed3"	Configure the chart speed 3 <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>1 to 1500</td> <td>1 to 1500</td> </tr> <tr> <td>12.5 *</td> <td>12.5 *</td> </tr> </table>	Software screen	Instrument screen	1 to 1500	1 to 1500	12.5 *	12.5 *	
Software screen	Instrument screen							
1 to 1500	1 to 1500							
12.5 *	12.5 *							

## 6-6-7. Analog Recording (Dot Printing Type) Settings "Dot"

- The analog recording (dot printing type) settings for the input channels are displayed in the table format to enable you to edit them.
  - The columns of the table present the setting parameter types, and the rows present the channel numbers.
  - For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.
  - The number of the displayed channels varies depending on the instrument model.
- \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the chart speed settings.

#### [Analog Recording (MultiPoint Type) Settings "Dot" Parameter List]

Setting parameter	Function	Remarks														
Color "Color"	Select the chart color <table border="1"> <tr> <th>Software screen</th><th>Instrument screen</th></tr> <tr> <td>Red</td><td>Red</td></tr> <tr> <td>Black</td><td>Black</td></tr> <tr> <td>Blue</td><td>Blue</td></tr> <tr> <td>Green</td><td>Green</td></tr> <tr> <td>Brown</td><td>Brown</td></tr> <tr> <td>Purple</td><td>Purple</td></tr> </table>	Software screen	Instrument screen	Red	Red	Black	Black	Blue	Blue	Green	Green	Brown	Brown	Purple	Purple	
Software screen	Instrument screen															
Red	Red															
Black	Black															
Blue	Blue															
Green	Green															
Brown	Brown															
Purple	Purple															
Record "Rec"	Specify whether the analog recording is turned on or off <table border="1"> <tr> <th>Software screen</th><th>Instrument screen</th></tr> <tr> <td>Record</td><td>ON</td></tr> <tr> <td>Do Not Record</td><td>OFF</td></tr> </table>	Software screen	Instrument screen	Record	ON	Do Not Record	OFF									
Software screen	Instrument screen															
Record	ON															
Do Not Record	OFF															

## 6-6-8. Subtract Printing Settings "Sub Prt"

- The subtract printing settings for the input channels are displayed in the table format to enable you to edit them.
- The columns of the table present the setting parameter types, and the rows present the channel numbers.
- For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.
- The number of the displayed channels varies depending on the instrument model.  
\* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the subtract printing settings.

#### [Subtract Printing Settings "Sub Prt" Parameter List]

Setting parameter	Function	Remarks								
"Kind"	Specify the kind of subtract printing <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>Set the standard CH to [None]</td><td>None</td></tr> <tr><td>Set the standard CH and difference CH to other than [None]</td><td>CH.X - CH.Y</td></tr> <tr><td>Set the difference CH to [None]</td><td>CH.X - Const</td></tr> </table>	Software screen	Instrument screen	Set the standard CH to [None]	None	Set the standard CH and difference CH to other than [None]	CH.X - CH.Y	Set the difference CH to [None]	CH.X - Const	There is no option on the software side corresponding to "Kind". The kind of the subtract printing ("Kind") is determined by setting these parameters.
Software screen	Instrument screen									
Set the standard CH to [None]	None									
Set the standard CH and difference CH to other than [None]	CH.X - CH.Y									
Set the difference CH to [None]	CH.X - Const									
Standard CH "CH.X"	Specify the measurement CH to be subtracted from CH.X <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 24</td><td>1 to 24</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 24	1 to 24	The number of the displayed channels varies depending on the instrument model.		
Software screen	Instrument screen									
None	-									
1 to 24	1 to 24									
Difference CH "CH.Y"	Specify the measurement CH to subtract <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 24</td><td>1 to 24</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 24	1 to 24	The number of the displayed channels varies depending on the instrument model.		
Software screen	Instrument screen									
None	-									
1 to 24	1 to 24									
Constant "Const"	Specify the reference value to be subtracted from CH.X	-30000 to 99999 The decimal location changes according to the one of the scale								
Record Range Lower Limit "Sub.REC-L"	Specify the lower limit of the subtract record range when recording the chart	When the standard CH is set to [None], the decimal location is 0								
Record Range Upper Limit "Sub.REC-H"	Specify the upper limit of the subtract record range when recording the chart	When online, an overflow value is displayed as "#####"								

## 2. Copy and paste operations for subtract printing setting

For the subtract printing setting, you can copy and paste parameters per channel (parameters belonging to one channel).

### <How to copy/paste>

#### (1) Select the copy source


Click to select a channel number or any column to copy from.

- \* You can copy parameters per one channel. That means, you cannot select multiple channels to copy the parameters at a time.



#### (2) Click the [Copy] button


Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


Click to select a channel number or any column to paste to.

- \* You can paste the parameters to one channel. That means, you cannot select multiple channels to paste the parameters at a time.



#### (4) Click the [Paste] button

Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks → "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one channel.

## 6-6-9. Analog Recording (Trace Printing Interval) Settings "Dot.Int"

- The settings for the analog recording (trace printing interval) are displayed to enable you to edit them.
- For AL4000/AH4000, you can edit these settings.  
\* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the analog recording (trace printing interval) settings.

#### [Analog Recording (Trace Printing Interval) Settings "Dot.Int" Parameter List]

Setting parameter	Function	Remarks								
Analog Recording (Trace Printing Interval) "Dot-Interval"	Specify the trace printing interval <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>Normal (5 sec.)</td><td>Normal</td></tr><tr><td>Quick (2.5 sec.)</td><td>Fast</td></tr><tr><td>Chart Synchronization</td><td>Synchro</td></tr></table>	Software screen	Instrument screen	Normal (5 sec.)	Normal	Quick (2.5 sec.)	Fast	Chart Synchronization	Synchro	
Software screen	Instrument screen									
Normal (5 sec.)	Normal									
Quick (2.5 sec.)	Fast									
Chart Synchronization	Synchro									

## 6-6-10. Periodic (Data Interval) Data Printing Settings "DataInt"

- The settings for the periodic data printing are displayed in the [Data Interval] and [Specified Time] tabs to enable you to edit them.
  - In the [Data Interval] tab, the start time and the interval are displayed. The left field presents the hour (time) and the hours (interval), and the right one presents the minute (time) and the minutes (interval). In [Status] above the tabs, the setting status (interval) is displayed.
  - If you set 0 hours and 1 minute or longer in [Interval], the interval printing is enabled ("Interval" is displayed in [Status]).
  - You can specify per channel whether the measured data is printed or not by switching [Record] and [Do Not Record] in [Digital Recording/Printing] for the range settings (refer to section 6-6-1).
  - For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.
- \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the periodic (data interval) data printing settings.

#### [Periodic (Data Interval) Data Printing Settings "DataInt" Parameter List]


Setting parameter	Function	Remarks
Start Time "StartTime"	Specify the start time of the periodic data printing (If you specify the time earlier than the current time, the start time is set to the same time on the next day)	
Interval "Interval"	Specify the interval (hours and minutes) to print the measurement value as a numerical number (The maximum value is 24 hours and 1 minute step)	When the interval is 0 hours and 0 minutes, "None" is displayed in [Status]. When it is another value, "Interval" is displayed in [Status].

\* When you want to use an interval in the periodic data printing, set the interval to 0 hours and 1 minute or longer.

When you want to use the specified time in the periodic data printing, reset the interval to 0 hours and 0 minutes.

## 6-6-11. Periodic (Specified Time) Data Printing Settings "PrtTime"

- The settings for the periodic data printing are displayed in the [Data Interval] and [Specified Time] tabs to enable you to edit them.
- In the [Specified Time] tab, the columns of the table present the setting parameter types and the rows present the specified time numbers. In [Status] above the tabs, the setting status (specified time) is displayed.
- When you set the interval to 0 hours and 0 minutes in [Data Interval] (refer to section 6-6-10) and select the [Use Specified Time] check box , the specified time printing is enabled ("Specified Time" is displayed in [Status]). You can register 24 specified times at a maximum.
- You can specify per channel whether the measured data is printed or not by switching [Record] and [Do Not Record] in [Digital Recording/Printing] for the range settings (refer to section 6-6-1).
- For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the periodic (specified time) data printing settings.

[Periodic (Specified Time) Data Printing Settings "PrtTime" Parameter List]

Setting parameter	Function	Remarks										
Specified Time "PrintTime"	<p>Specify whether the specified time recording is turned on or off</p> <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Switch ON and OFF using the check box</td> <td>Switch ON and Off using the F1 key</td> </tr> </table> <p>Specify the interval (hours and minutes) to print the measurement value as a numerical number</p> <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>0 to 23* hour</td> <td>00 to 23* Hour</td> </tr> <tr> <td>0 to 59 minute</td> <td>00 to 59 Min</td> </tr> </table> <p>* "-" (not use) can be set for the hour.</p>	Software screen	Instrument screen	Switch ON and OFF using the check box	Switch ON and Off using the F1 key	Software screen	Instrument screen	0 to 23* hour	00 to 23* Hour	0 to 59 minute	00 to 59 Min	When you set the interval to 0 hours and 0 minutes and you use the specified time, "Specified Time" is displayed in [Status].
Software screen	Instrument screen											
Switch ON and OFF using the check box	Switch ON and Off using the F1 key											
Software screen	Instrument screen											
0 to 23* hour	00 to 23* Hour											
0 to 59 minute	00 to 59 Min											

\* Even if you set the interval to a value other than 0 hours and 0 minutes in [Data Interval], you can enter the specified time. Note that, when you want to use the specified time in [Periodic Data Printing], be sure to set the interval to 0 hours and 0 minutes and select the [Use Specified Time]  check box.

## 2. Copy and paste operations for periodic (specified time) data printing setting


For the periodic (specified time) settings, you can copy and paste parameters per specified time number (parameters belonging to one specified time number).

### <How to copy/paste>

#### (1) Select the copy source


Click to select a specific time number or any column to copy from.

- \* You can copy parameters per one specified time number. That means, you cannot select multiple specified time numbers to copy the parameters at a time.



#### (2) Click the [Copy] button


Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


Click to select a specified time number or any column to paste to.

- \* You can paste the parameters to one specified time number. That means, you cannot select multiple specified time numbers to paste the parameters at a time.



#### (4) Click the [Paste] button

Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks → "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one specified time number.

## 6-6-12. Message Printing 1 Settings "MsgPrt1"

- The settings for the message printing 1 are displayed in the table format to enable you to edit them.
- The columns of the table present the setting parameter types, and the rows present the message numbers. When you connect to the instrument and in online, you can specify any number in [Select Message No.] above the table to print a message in the connected instrument.
- For example, you can work with the settings of the calendar timer (refer to section 6-6-27) or the external drive (refer to section 6-6-28) to print a registered message.
- When you select [Online] in the Parameter Setting Menu screen, you can send a message selected by the message No. to the instrument to print it. When you select [Offline], you cannot print a message.
- For AL4000/AH4000, you can edit these settings.

\* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the message printing 1 settings.

#### [Message Printing 1 Settings "MsgPrt1" Parameter List]

Setting parameter	Function	Remarks														
Message "Message"	Set the number of characters to be printed using up to 15 characters  You can register 20 messages at a maximum	Available characters (one byte): ABCDEFGHIJKLMNPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz 0123456789+-*/%^()._.;<>=!=[]¥ (refer to section 6-1-2)														
Color "Color"	Select the message print color <table border="1"> <tr> <th>Software screen</th> <th>Instrument screen</th> </tr> <tr> <td>Red</td> <td>Red</td> </tr> <tr> <td>Black</td> <td>Black</td> </tr> <tr> <td>Blue</td> <td>Blue</td> </tr> <tr> <td>Green</td> <td>Green</td> </tr> <tr> <td>Brown</td> <td>Brown</td> </tr> <tr> <td>Purple</td> <td>Purple</td> </tr> </table>	Software screen	Instrument screen	Red	Red	Black	Black	Blue	Blue	Green	Green	Brown	Brown	Purple	Purple	
Software screen	Instrument screen															
Red	Red															
Black	Black															
Blue	Blue															
Green	Green															
Brown	Brown															
Purple	Purple															

## 2. Copy and paste operations for message printing 1 setting


For the message printing 1 settings, you can copy and paste parameters per message number (parameters belonging to one message number).

### <How to copy/paste>

#### (1) Select the copy source


Click to select a specific time number or any column to copy from.

- \* You can copy parameters per one message number. That means, you cannot select multiple message numbers to copy the parameters at a time.



#### (2) Click the [Copy] button


Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


Click to select a message number or any column to paste to.

- \* You can paste the parameters to one message number. That means, you cannot select multiple message numbers to paste the parameters at a time.



#### (4) Click the [Paste] button

Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks > "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one message number.

## 6-6-13. Message Printing 2 Settings "MsgPrt2"

- The message printing 2 settings are displayed to enable you to edit them.
- When you select [Online] in the Parameter Setting Menu screen, you can send an input message to the instrument to print it. When you select [Offline], you cannot print a message.
- For AL4000/AH4000, you can edit these settings.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the message printing 2 settings.

#### [Message Printing 2 Settings "MsgPrt2" Parameter List]

Setting parameter	Function	Remarks														
Message "Message"	<b>For AL4000 or KL4000</b> Set the number of characters to be printed using up to 40 characters <b>For AH4000 or KH4000</b> Set the number of characters to be printed using up to 72 characters	Available characters (one byte): ABCDEFGHIJKLMNOPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz 0123456789+*/%^()_.;,>=!=![]¥ (refer to section 6-1-2)														
5mm Feeding "5mm Feed"	Select the feeding before printing a message <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>No Feed</td> <td>No</td> </tr> <tr> <td>Feed</td> <td>Yes</td> </tr> </table>	Software screen	Instrument screen	No Feed	No	Feed	Yes									
Software screen	Instrument screen															
No Feed	No															
Feed	Yes															
Color "Color"	Select the message print color <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Red</td> <td>Red</td> </tr> <tr> <td>Black</td> <td>Black</td> </tr> <tr> <td>Blue</td> <td>Blue</td> </tr> <tr> <td>Green</td> <td>Green</td> </tr> <tr> <td>Brown</td> <td>Brown</td> </tr> <tr> <td>Purple</td> <td>Purple</td> </tr> </table>	Software screen	Instrument screen	Red	Red	Black	Black	Blue	Blue	Green	Green	Brown	Brown	Purple	Purple	
Software screen	Instrument screen															
Red	Red															
Black	Black															
Blue	Blue															
Green	Green															
Brown	Brown															
Purple	Purple															

## 6-6-14. Recording Format Settings "PrtForm"

- The recording format settings are displayed to enable you to edit them.
- When you select [Automatic Range] or [Automatic Range (Overlap)] in [Recording Format], the automatic range switching (printing) settings (refer to section 6-6-15) is required. When you select [Compressed/Expanded Printing] and [Zone Printing], the compressed/expanded printing settings (refer to section 6-6-16) and zone printing settings (refer to section 6-6-17) are required, respectively.
- For AL4000/AH4000, you can edit these settings.  
*\* Refer to the instruction manual of the instrument for more details on the settings.*



### 1. Parameter setting


You can configure the following parameters in the recording format settings.

#### [Recording Format Settings "PrtForm" Parameter List]

Setting parameter	Function	Remarks												
Recording Format "Printing Format"	Select the recording format <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>Standard</td><td>Standard</td></tr><tr><td>Automatic Range</td><td>Auto Range Normal</td></tr><tr><td>Compressed/Expanded Printing</td><td>Comp.&amp;Exp.Print</td></tr><tr><td>Zone Printing</td><td>Zone Print</td></tr><tr><td>Automatic Range (Overlap)</td><td>Auto Range Overlap</td></tr></table>	Software screen	Instrument screen	Standard	Standard	Automatic Range	Auto Range Normal	Compressed/Expanded Printing	Comp.&Exp.Print	Zone Printing	Zone Print	Automatic Range (Overlap)	Auto Range Overlap	
Software screen	Instrument screen													
Standard	Standard													
Automatic Range	Auto Range Normal													
Compressed/Expanded Printing	Comp.&Exp.Print													
Zone Printing	Zone Print													
Automatic Range (Overlap)	Auto Range Overlap													

## 6-6-15. Automatic Range Switching (Printing) Settings "A.Range"

- The automatic range switching (printing) settings are displayed in the table format to enable you to edit them.
- The columns of the table present the setting parameter types, and the rows present the automatic range switching types (Standard and Overlap) and channel numbers.
- There are two types, "automatic range (standard)" where the minimum-to-maximum ranges do not overlap, and "automatic range (overlap)" where they overlap.
- For AL4000/AH4000, you can edit these settings.
- The number of the displayed channels vary depending on the instrument model.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the automatic range switching (printing) settings.

#### [Automatic Range Switching (Printing) Settings "A.Range" Parameter List]

Setting parameter	Function	Remarks						
"Auto Range ON/OFF"	Enable or disable the auto range settings <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Software screen</td><td style="width: 50%;">Instrument screen</td></tr> <tr> <td>Use the following maximum and minimum range settings</td><td>ON</td></tr> <tr> <td></td><td>OFF</td></tr> </table>	Software screen	Instrument screen	Use the following maximum and minimum range settings	ON		OFF	Switch ON (enter a value) or OFF (none) using the minimum and maximum setting parameters for each range.
Software screen	Instrument screen							
Use the following maximum and minimum range settings	ON							
	OFF							
Min. In First Range "1st Min"	Set the minimum value of the first range	-30000 to 99999 The decimal location changes according to the one of the scale When online, an overflow value is displayed as "#####"						
Max. In First Range "1st Max"	Set the maximum value of the first range							
Max. In Second Range "2nd Max"	Set the maximum value of the second range							
Max. In Third Range "3rd Max"	Set the maximum value of the third range							
Max. In Fourth Range "4th Max"	Set the maximum value of the forth range							
Max. In Fifth Range "5th Max"	Set the maximum value of the fifth range							


## 2. Copy and paste operations for automatic range switching (printing) setting

For the automatic range switching (printing) setting, you can copy and paste parameters per one channel number (parameters belonging to one channel number).

### <How to copy/paste>

#### (1) Select the copy source

- Click to select a channel number or any column to copy from.
- \* You can copy parameters per one channel number. That means, you cannot select multiple channel numbers to copy the parameters at a time.



#### (2) Click the [Copy] button

- Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


- Click to select a channel number or any column to paste to.

- \* You can paste the parameters to one channel number. That means, you cannot select multiple channel numbers to paste the parameters at a time.



#### (4) Click the [Paste] button

- Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks → "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one channel number.

## 6-6-16. Compressed/Expanded Printing Settings "Cmp&Exp"

- The settings for the compressed/expanded printing settings are displayed in the table format to enable you to edit them.
- The columns of the table present the setting parameter types, and the rows present the channel numbers.
- For AL4000/AH4000, you can edit these settings.
- The number of the displayed channels varies depending on the instrument model.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the compressed/expanded printing settings.

[Compressed/Expanded Printing Settings "Cmp&Exp" Parameter List]

Setting parameter	Function	Remarks						
0%Scale "SCALE-0"	Specify the recording scale for the recording position (0%) <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>-30000 to 99999</td><td>-30000 to 99999</td></tr> </table>	Software screen	Instrument screen	None	-	-30000 to 99999	-30000 to 99999	The decimal location changes according to the one of the scale When online, an overflow value is displayed as "# #####"
Software screen	Instrument screen							
None	-							
-30000 to 99999	-30000 to 99999							
1st Break Point Recording Position (%) "POS-1st"	Specify the recording point for the first break point in proportion to the span (%) <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 99</td><td>1 to 99</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 99	1 to 99	
Software screen	Instrument screen							
None	-							
1 to 99	1 to 99							
1st Break Point Scale "SCALE-1st"	Specify the recording scale for the first break point	See the remarks of "0% Scale " for details						
2nd Break Point Recording Position (%) "POS-2nd"	Specify the recording point for the second break point in proportion to the span (%) <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 99</td><td>1 to 99</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 99	1 to 99	
Software screen	Instrument screen							
None	-							
1 to 99	1 to 99							
2nd Break Point Scale "SCALE-2nd"	Specify the recording scale for the second break point	See the remarks of "0% Scale " for details						
100%Scale "SCALE-100"	Specify the recording scale for the recording position (100%)	-30000 to 99999 See the remarks of "0% Scale " for details						


## 2. Copy and paste operations for compressed/expanded printing setting

For the compressed/expanded printing setting, you can copy and paste parameters per one channel number (parameters belonging to one channel number).

### <How to copy/paste>


#### (1) Select the copy source

- Click to select a channel number or any column to copy from.
- \* You can copy parameters per one channel number. That means, you cannot select multiple channel numbers to copy the parameters at a time.




#### (2) Click the [Copy] button

- Click the [Copy] button from the tool bar to copy the selected parameters.




#### (3) Select the paste destination

- Click to select a channel number or any column to paste to.
- \* You can paste the parameters to one channel number. That means, you cannot select multiple channel numbers to paste the parameters at a time.



#### (4) Click the [Paste] button

- Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks > "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one channel number.

## 6-6-17. Zone Printing Settings "ZonePrt"

- The split number settings of zone printings are displayed in the table format to enable you to edit them.
- Specify the number of divided areas in [Split Number] above the table. The columns of the table present the types of divided areas, and the rows present the setting parameter types.
- For AL4000/AH4000, you can edit these settings.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the zone printing settings.

**[Zone Printing Settings "Zoneprt" Parameter List]**


Setting parameter	Function	Remarks														
Split Number "Zone"	Specify the split number for the zone printing <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>2 to 4</td> <td>2 to 4</td> </tr> </table>	Software screen	Instrument screen	2 to 4	2 to 4	For AL4000, the split number is fixed to 2										
Software screen	Instrument screen															
2 to 4	2 to 4															
Type "Type"	Area setting format <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>CH.X</td> <td>CH.X</td> </tr> <tr> <td>CH.X/CH.Y</td> <td>CH.X/CH.Y</td> </tr> <tr> <td>CH.X-CH.Y</td> <td>CH.X-CH.Y</td> </tr> <tr> <td>CH.X/CH.Y/CH.Z</td> <td>CH.X/CH.Y/CH.Z</td> </tr> <tr> <td>CH.X-CH.Y/CH.Z</td> <td>CH.X-CH.Y/CH.Z</td> </tr> <tr> <td>CH.X/CH.Y-CH.Z</td> <td>CH.X/CH.Y-CH.Z</td> </tr> </table>	Software screen	Instrument screen	CH.X	CH.X	CH.X/CH.Y	CH.X/CH.Y	CH.X-CH.Y	CH.X-CH.Y	CH.X/CH.Y/CH.Z	CH.X/CH.Y/CH.Z	CH.X-CH.Y/CH.Z	CH.X-CH.Y/CH.Z	CH.X/CH.Y-CH.Z	CH.X/CH.Y-CH.Z	<b>CH.X</b> Dot CH.X in the specified area <b>CH.X/CH.Y</b> Dot CH.X and CH.Y in the specified area <b>CH.X-CH.Y</b> Dot CH.X - CH.Y in the specified area <b>CH.X/CH.Y/CH.Z</b> Dot CH.X, CH.Y, and CH.Z in the specified area <b>CH.X-CH.Y/CH.Z</b> Dot CH.X - CH.Y and CH.Z in the specified area <b>CH.X/CH.Y-CH.Z</b> Dot CH.X and CH.Y - CH.Z in the specified area
Software screen	Instrument screen															
CH.X	CH.X															
CH.X/CH.Y	CH.X/CH.Y															
CH.X-CH.Y	CH.X-CH.Y															
CH.X/CH.Y/CH.Z	CH.X/CH.Y/CH.Z															
CH.X-CH.Y/CH.Z	CH.X-CH.Y/CH.Z															
CH.X/CH.Y-CH.Z	CH.X/CH.Y-CH.Z															
CH.X	Software screen <table border="1"> <tr> <td>-</td> <td>-</td> </tr> <tr> <td>1 to 24</td> <td>1 to 24</td> </tr> </table>	-	-	1 to 24	1 to 24	The number of the displayed channels vary depending on the instrument model.										
-	-															
1 to 24	1 to 24															

**Remarks** **CH selection**

Channels selected for no areas are skipped.

## 6-6-18. SD Card Settings "SD CARD"

- The SD card settings are displayed to enable you to edit them.
- For AL4000/AH4000, you can edit these settings.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the SD card settings.


**[SD Card Settings "Recording data-Saving" Parameter List]**

Setting parameter	Function	Remarks																
Recording Format "Format"	Select the recording format of the SD card <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Software screen</td><td style="width: 50%;">Instrument screen</td></tr> <tr> <td>Binary</td><td>Binary</td></tr> <tr> <td>Text</td><td>Text</td></tr> <tr> <td>Binary (Floating Decimal Point)</td><td>Binary (float)</td></tr> <tr> <td>Text (Floating Decimal Point)</td><td>Text (float)</td></tr> </table>	Software screen	Instrument screen	Binary	Binary	Text	Text	Binary (Floating Decimal Point)	Binary (float)	Text (Floating Decimal Point)	Text (float)							
Software screen	Instrument screen																	
Binary	Binary																	
Text	Text																	
Binary (Floating Decimal Point)	Binary (float)																	
Text (Floating Decimal Point)	Text (float)																	
Record Interval "Interval"	Select the recording interval of the SD card <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Software screen</td><td style="width: 50%;">Instrument screen</td></tr> <tr> <td>1 Second, 2 Seconds, (3 Seconds), (4 Seconds), (5 Seconds), (6 Seconds), 10 Seconds, (15 Seconds), (16 Seconds), 20 Seconds, 30 Seconds, 1 Minute, 2 Minutes, 3 Minutes, 5 Minutes, 10 Minutes, 15 Minutes, 20 Minutes, 30 Minutes, 60 Minutes</td><td>1sec, 2sec, (3sec), (4sec), (5sec), (6sec), 10sec, (15sec), (16sec), 20sec, 30sec, 1min, 2min, 3min, 5min, 10min, 15min, 20min, 30min, 60min</td></tr> </table> Values in parentheses :- The recording interval options vary depending on the number of inputs.	Software screen	Instrument screen	1 Second, 2 Seconds, (3 Seconds), (4 Seconds), (5 Seconds), (6 Seconds), 10 Seconds, (15 Seconds), (16 Seconds), 20 Seconds, 30 Seconds, 1 Minute, 2 Minutes, 3 Minutes, 5 Minutes, 10 Minutes, 15 Minutes, 20 Minutes, 30 Minutes, 60 Minutes	1sec, 2sec, (3sec), (4sec), (5sec), (6sec), 10sec, (15sec), (16sec), 20sec, 30sec, 1min, 2min, 3min, 5min, 10min, 15min, 20min, 30min, 60min	<p><b>In case of 6 inputs</b> [3 Seconds], [5 Seconds], and [15 Seconds] are displayed ([4 Seconds], [6 Seconds], and [16 Seconds] are not displayed)</p> <p><b>In case of 12 and 24 inputs</b> [4 Seconds], [6 Seconds], and [16 Seconds] are displayed ([3 Seconds], [5 Seconds], and [15 Seconds] are not displayed)</p>												
Software screen	Instrument screen																	
1 Second, 2 Seconds, (3 Seconds), (4 Seconds), (5 Seconds), (6 Seconds), 10 Seconds, (15 Seconds), (16 Seconds), 20 Seconds, 30 Seconds, 1 Minute, 2 Minutes, 3 Minutes, 5 Minutes, 10 Minutes, 15 Minutes, 20 Minutes, 30 Minutes, 60 Minutes	1sec, 2sec, (3sec), (4sec), (5sec), (6sec), 10sec, (15sec), (16sec), 20sec, 30sec, 1min, 2min, 3min, 5min, 10min, 15min, 20min, 30min, 60min																	
Recording Start Trigger Selecting "Start TRG."	Select the trigger to start the recording <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Software screen</td><td style="width: 50%;">Instrument screen</td></tr> <tr> <td>None</td><td>None</td></tr> <tr> <td>Key</td><td>Key ([REC+FUNC1])</td></tr> <tr> <td>Specified Time</td><td>StartTime</td></tr> <tr> <td>Linked to Alarm Output</td><td>Alarm</td></tr> <tr> <td>Linked to External Drive</td><td>EX</td></tr> <tr> <td>Linked to Chart</td><td>Chart</td></tr> <tr> <td>Linked to Chart End</td><td>Chart End</td></tr> </table>	Software screen	Instrument screen	None	None	Key	Key ([REC+FUNC1])	Specified Time	StartTime	Linked to Alarm Output	Alarm	Linked to External Drive	EX	Linked to Chart	Chart	Linked to Chart End	Chart End	
Software screen	Instrument screen																	
None	None																	
Key	Key ([REC+FUNC1])																	
Specified Time	StartTime																	
Linked to Alarm Output	Alarm																	
Linked to External Drive	EX																	
Linked to Chart	Chart																	
Linked to Chart End	Chart End																	

Start Time "StartTime"	Specify the recording start time if you select [Specified Time] "StartTime" in [Trigger Selecting] "Start TRG." <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>00 to 23 (Hour)</td><td>00 to 23 Hour</td></tr> <tr><td>00 to 59 (Minute)</td><td>00 to 59 Min</td></tr> </table>	Software screen	Instrument screen	00 to 23 (Hour)	00 to 23 Hour	00 to 59 (Minute)	00 to 59 Min									
Software screen	Instrument screen															
00 to 23 (Hour)	00 to 23 Hour															
00 to 59 (Minute)	00 to 59 Min															
Pre-Trigger Sample Number "PreTrigger"	The specified number of previous samples are recorded together to the SD card when starting the recording <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>0 to 10</td><td>0 to 10</td></tr> </table>	Software screen	Instrument screen	0 to 10	0 to 10											
Software screen	Instrument screen															
0 to 10	0 to 10															
Record End Trigger Selecting "End TRG."	Select the trigger to end the recording <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>Key</td><td>Key ([REC+FUNC1])</td></tr> <tr><td>Specified Time</td><td>Rec.time</td></tr> <tr><td>Linked to Alarm Output</td><td>Alarm</td></tr> <tr><td>Linked to External Drive</td><td>EX</td></tr> <tr><td>Linked to Chart</td><td>Chart</td></tr> <tr><td>Linked to Chart End</td><td>Chart End</td></tr> </table>	Software screen	Instrument screen	Key	Key ([REC+FUNC1])	Specified Time	Rec.time	Linked to Alarm Output	Alarm	Linked to External Drive	EX	Linked to Chart	Chart	Linked to Chart End	Chart End	
Software screen	Instrument screen															
Key	Key ([REC+FUNC1])															
Specified Time	Rec.time															
Linked to Alarm Output	Alarm															
Linked to External Drive	EX															
Linked to Chart	Chart															
Linked to Chart End	Chart End															
Record Time "Rec.time"	Specify the record time if you select [Specified Time] "Rec.time" in [Trigger Selecting] "End TRG." <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>00 to 99 hours</td><td>00 to 99 Hour</td></tr> <tr><td>00 to 59 minutes</td><td>00 to 59 Min</td></tr> </table>	Software screen	Instrument screen	00 to 99 hours	00 to 99 Hour	00 to 59 minutes	00 to 59 Min									
Software screen	Instrument screen															
00 to 99 hours	00 to 99 Hour															
00 to 59 minutes	00 to 59 Min															
Synchronize Destination Output No. "Relay No."	Specify the linking alarm output No. if you select [Alarm] in [Start TRG/End TRG] <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 24</td><td>1 to 24</td></tr> <tr><td>Dummy Output</td><td>99</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 24	1 to 24	Dummy Output	99	The displayed number varies depending on the instrument model.						
Software screen	Instrument screen															
None	-															
1 to 24	1 to 24															
Dummy Output	99															
Synchronize Destination Drive No. (Only External Drive) "EX No."	Specify the linking external drive No. if you select [EX] in [Start TRG/End TRG] <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>00</td></tr> <tr><td>1 to 20</td><td>1 to 20</td></tr> </table>	Software screen	Instrument screen	None	00	1 to 20	1 to 20	The displayed number varies depending on the instrument model.								
Software screen	Instrument screen															
None	00															
1 to 20	1 to 20															

## 6-6-19. USB Engineering Port Settings "USB"

- The USB engineering port settings are displayed to enable you to edit them.
- For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.
  - \* When using this software, set [Mode] to [BULK] and [USB ID] to [1] on the connected instrument.
  - \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the USB engineering port settings.

#### [USG Engineering Port Settings "USB" Parameter List]

Setting parameter	Function	Remarks						
Connection Mode "Mode"	Select the connection mode <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>Individual Protocol</td><td>BULK</td></tr><tr><td>VCP</td><td>VCP</td></tr></table>	Software screen	Instrument screen	Individual Protocol	BULK	VCP	VCP	[VCP] is displayed but cannot be selected.
Software screen	Instrument screen							
Individual Protocol	BULK							
VCP	VCP							
Identification Id "USB ID Address"	The USB identification address when you select the individual protocol [BULK] in the connection mode [Mode] <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>1 to 5</td><td>1 to 5</td></tr></table>	Software screen	Instrument screen	1 to 5	1 to 5			
Software screen	Instrument screen							
1 to 5	1 to 5							

## 6-6-20. COM1 (Communication) Settings "COM1"

- The COM1 (communication) settings are displayed to enable you to edit them.
- For AL4000/AH4000 or KL4000/KH4000 with the communication method, you can edit these settings (refer to the table \* 1 in section 6-1-5).
- \* Refer to the instruction manual of the instrument and the manual for communication interface for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the COM1 (communication) settings.

#### [COM1 (Communication) Settings "COM1" Parameter List]

Setting parameter	Function	Remarks										
Mode "Mode"	Select "Low Order" (the instrument is low order) or "High Order" (the instrument is high order) for the communication mode <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>Low Order (Connected to PC)</td><td>Low (To PC etc...)</td></tr><tr><td>High Order (Connected to Instruments)</td><td>High (To DB/KP etc...)</td></tr></table>	Software screen	Instrument screen	Low Order (Connected to PC)	Low (To PC etc...)	High Order (Connected to Instruments)	High (To DB/KP etc...)	"High Order (Connected to Instruments)" is displayed, but cannot be selected.				
Software screen	Instrument screen											
Low Order (Connected to PC)	Low (To PC etc...)											
High Order (Connected to Instruments)	High (To DB/KP etc...)											
Protocol "Protocol"	Select the communications protocol <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>MODBUS RTU</td><td>MODBUS RTU</td></tr><tr><td>MODBUS ASCII</td><td>MODBUS ASCII</td></tr><tr><td>PRIVATE (without connection sequence)</td><td>PRIVATE1</td></tr><tr><td>PRIVATE (with connection sequence)</td><td>PRIVATE2</td></tr></table>	Software screen	Instrument screen	MODBUS RTU	MODBUS RTU	MODBUS ASCII	MODBUS ASCII	PRIVATE (without connection sequence)	PRIVATE1	PRIVATE (with connection sequence)	PRIVATE2	
Software screen	Instrument screen											
MODBUS RTU	MODBUS RTU											
MODBUS ASCII	MODBUS ASCII											
PRIVATE (without connection sequence)	PRIVATE1											
PRIVATE (with connection sequence)	PRIVATE2											
Address "Address"	Set the communication address of the instrument <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>01 to 99</td><td>01 to 99</td></tr></table>	Software screen	Instrument screen	01 to 99	01 to 99							
Software screen	Instrument screen											
01 to 99	01 to 99											
Transmitting Speed "Baudrate"	Set the communication speed* <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>1200, 2400, 4800, 9600, 19200, 38400</td><td>1200, 2400, 4800, 9600, 19200, 38400</td></tr></table>	Software screen	Instrument screen	1200, 2400, 4800, 9600, 19200, 38400	1200, 2400, 4800, 9600, 19200, 38400	* PRIVATE: 1200, 2400, 4800, 9600bps MODBUS: 9600, 19200, 38400bps This changes to "9600" when the protocol is changed to PRIVATE from MODBUS or vice versa.						
Software screen	Instrument screen											
1200, 2400, 4800, 9600, 19200, 38400	1200, 2400, 4800, 9600, 19200, 38400											
Transmitting Character "Character"	Set the transmitting character* <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>7E1, 7E2, 7O1, 7O2, 8N1, 8N2, 8E1, 8E2, 8O1, 8O2</td><td>7E1, 7E2, 7O1, 7O2, 8N1, 8N2, 8E1, 8E2, 8O1, 8O2</td></tr></table>	Software screen	Instrument screen	7E1, 7E2, 7O1, 7O2, 8N1, 8N2, 8E1, 8E2, 8O1, 8O2	7E1, 7E2, 7O1, 7O2, 8N1, 8N2, 8E1, 8E2, 8O1, 8O2	* All options are displayed except for the following protocol MODBUS RTU: Only 8N1, 8N2, 8E1, 8E2, 8O1, and 8O2 are displayed						
Software screen	Instrument screen											
7E1, 7E2, 7O1, 7O2, 8N1, 8N2, 8E1, 8E2, 8O1, 8O2	7E1, 7E2, 7O1, 7O2, 8N1, 8N2, 8E1, 8E2, 8O1, 8O2											
Check Sum "Check SUM"	Select whether or not to add checksum code* <table border="1"><tr><td>Software screen</td><td>Instrument screen</td></tr><tr><td>None</td><td>OFF</td></tr><tr><td>Exists</td><td>ON</td></tr></table>	Software screen	Instrument screen	None	OFF	Exists	ON	* Available only when the protocol is set to "PRIVATE (without connection sequence)" or "PRIVATE (with connection sequence)"				
Software screen	Instrument screen											
None	OFF											
Exists	ON											

## 6-6-21. COM2 (Communication) Settings "COM2"

- The COM2 (communication) settings are displayed to enable you to edit them.
- For AL4000/AH4000 with the communication method, you can edit these settings (refer to the table \* 1 in section 6-1-5).
  - Refer to the instruction manual of the instrument and the manual for communication interface for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the COM2 (communication) settings.

[COM2 (Communication) Settings "COM2" Parameter List]

Setting parameter	Function		Remarks
Mode "Mode"	Select "Low Order" (the instrument is low order) or "High Order" (the instrument is high order) for the communication mode	Software screen Instrument screen Low Order (Connected to PC) High Order (Connected to Instruments)	"High Order (Connected to Instruments)" is displayed, but cannot be selected.
Protocol "Protocol"	Select the communications protocol	Software screen MODBUS RTU MODBUS ASCII PRIVATE (without connection sequence) PRIVATE (with connection sequence)	
Address "Address"	Set the communication address of the instrument	Software screen Instrument screen 01 to 99	
Transmitting Speed "Baudrate"	Set the communication speed*	Software screen 1200, 2400, 4800, 9600, 19200, 38400	* PRIVATE: 1200, 2400, 4800, 9600bps MODBUS: 9600, 19200, 38400bps This changes to "9600" when the protocol is changed to PRIVATE from MODBUS or vice versa.
Transmitting Character "Character"	Set the transmitting character*	Software screen 7E1, 7E2, 7O1, 7O2, 8N1, 8N2, 8E1, 8E2, 8O1, 8O2	* All options are displayed except for the following protocol MODBUS RTU: Only 8N1, 8N2, 8E1, 8E2, 8O1, and 8O2 are displayed
Check Sum "Check SUM"	Select whether or not to add checksum code*	Software screen Instrument screen None Exists	* Available only when the protocol is set to "PRIVATE (without connection sequence)" or "PRIVATE (with connection sequence)"

## 6-6-22. Ethernet Settings "Ether"

- The Ethernet settings are displayed to enable you to edit them.
- For AL4000/AH4000 with the communication method, you can edit these settings (refer to the table \* 1 in section 6-1-5).
  - \* Refer to the instruction manual of the instrument and the manual for communication interface for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the Ethernet settings.

[Ethernet Settings "Ether" Parameter List]

Setting parameter	Function		Remarks
"MAC Address"	Ethernet MAC address set in the instrument (Not displayed on the software screen. Only displayed on the instrument screen.)		Setting impossible
IP Address "IP Address"	Set the IP address		
	Software screen	Instrument screen	
	0.0.0.0 to 255.255.255.255	0.0.0.0 to 255.255.255.255	
Subnet Mask "Subnet Mask"	Set the subnet mask		
	Software screen	Instrument screen	
	0.0.0.0 to 255.255.255.255	0.0.0.0 to 255.255.255.255	
Default Gateway "Default Gateway"	Set the default gateway address of the network used		
	Software screen	Instrument screen	
	0.0.0.0 to 255.255.255.255	0.0.0.0 to 255.255.255.255	
TCP/IP Socket Communication Port Number "Port No."	Set the port number used for TCP/IP socket communication with the high-order		
	Software screen	Instrument screen	
	0 to 65535	0 to 65535	
DNS Used/Unused "DNS ON/OFF"	Select whether or not to use DNS (domain name server)		
	Software screen	Instrument screen	
	Unused	OFF	When DNS is not used, set the IP address
	Used	ON	When DNS is used, set the name of the SNTP, SMTP, or other server
Primary DNS Server "Primary Server"	Set the primary DNS server		
	Software screen	Instrument screen	
	0.0.0.0 to 255.255.255.255	0.0.0.0 to 255.255.255.255	
Secondary DNS Server "Secondary Server"	Set the secondary DNS server		
	Software screen	Instrument screen	
	0.0.0.0 to 255.255.255.255	0.0.0.0 to 255.255.255.255	
Login Password "Password"	Set a password consisting of up to 32 characters (one byte) used for setting on the Web		Available characters (one byte): ABCDEFGHIJKLMNOPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz 0123456789 (refer to section 6-1-2)

## 6-6-23. SNTP Settings "SNTP"

- The SNTP settings are displayed to enable you to edit them.
- For AL4000/AH4000 with the communication method, you can edit these settings (refer to the table \* 1 in section 6-1-5).
   
\* Refer to the instruction manual of the instrument and the manual for communication interface for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the SNTP settings.

#### [SNTP Settings "SNTP" Parameter List]

Setting parameter	Function	Remarks						
SNTP Used/Unused "ON/OFF"	Set whether or not to use the time setting function by SNTP <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Unused</td> <td>OFF</td> </tr> <tr> <td>Used</td> <td>ON</td> </tr> </table>	Software screen	Instrument screen	Unused	OFF	Used	ON	
Software screen	Instrument screen							
Unused	OFF							
Used	ON							
SNTP Server Name or IP Address "Server"	Set the name or IP address of the SNTP server using up to 32 characters (one byte) When DNS is used, set the server name When DNS is not used, set the IP address of the server Available characters (one byte): ABCDEFGHIJKLMNOPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz 0123456789+.^%&()._.;:>>!=![]¥ (refer to section 6-1-2)							
Synchronization Time "Std.TIME"	Set the reference time for query <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>00 to 23 (Hour)</td> <td>00 to 23 Hour</td> </tr> <tr> <td>00 to 59 (Minute)</td> <td>00 to 59 Min</td> </tr> </table>	Software screen	Instrument screen	00 to 23 (Hour)	00 to 23 Hour	00 to 59 (Minute)	00 to 59 Min	
Software screen	Instrument screen							
00 to 23 (Hour)	00 to 23 Hour							
00 to 59 (Minute)	00 to 59 Min							

## 6-6-24. Email Address (Account) Settings "E-mail Account"

- The email address (account) settings are displayed to enable you to edit them.
- For AL4000/AH4000 with the communication method, you can edit these settings (refer to the table \* 1 in section 6-1-5).
  - \* Refer to the instruction manual of the instrument and the manual for communication interface for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the email address (account) settings.

[Email Address (Account) Settings "E-mail Account" Parameter List]

Setting parameter	Function	Remarks								
POP3 Server Name Or IP Address "POP3 Server"	Set the name or IP address of the server used for POP3 authentication using up to 32 characters (one byte)	When DNS is used, set the server name When DNS is not used, set the IP address of the server Available characters (one byte): ABCDEFGHIJKLMNOPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz0123456789+-%^()._;<>!=![]¥ (refer to section 6-1-2)								
Port Number "POP3 Port" (POP3 server side)	Set the port number of the POP3 server <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Software screen</td> <td style="width: 50%;">Instrument screen</td> </tr> <tr> <td>0 to 65535</td> <td>0 to 65535</td> </tr> </table>	Software screen	Instrument screen	0 to 65535	0 to 65535	110 for standard server				
Software screen	Instrument screen									
0 to 65535	0 to 65535									
SMTP Server "SMTP Server"	Set the name or IP address of the SMTP server using up to 32 characters (one byte)	When DNS is used, set the server name When DNS is not used, set the IP address of the server The available characters are the same as those of the [POP3 Server Name Or IP Address] setting parameter								
Port Number "SMTP Port" (SMTP server side)	Set the port number of the SMTP server <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Software screen</td> <td style="width: 50%;">Instrument screen</td> </tr> <tr> <td>0 to 65535</td> <td>0 to 65535</td> </tr> </table>	Software screen	Instrument screen	0 to 65535	0 to 65535	25 for standard server				
Software screen	Instrument screen									
0 to 65535	0 to 65535									
User ID "User ID"	Set the Email account using up to 32 characters (one byte)	Available characters (one byte): ABCDEFGHIJKLMNOPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz0123456789+-._@ (refer to section 6-1-2)								
Password "Password"	Set the Email password using up to 32 characters (one byte)	The available characters are the same as those of the [POP3 Server Name Or IP Address] setting parameter								
Authentication Type "Authentication"	Authentication type used for accessing the transmission server <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Software screen</td> <td style="width: 50%;">Instrument screen</td> </tr> <tr> <td>None</td> <td>None</td> </tr> <tr> <td>POP</td> <td>POP</td> </tr> <tr> <td>APOP</td> <td>APOP</td> </tr> </table>	Software screen	Instrument screen	None	None	POP	POP	APOP	APOP	
Software screen	Instrument screen									
None	None									
POP	POP									
APOP	APOP									
Sender Email Address "Sender address"	Set the sender Email address using up to 32 characters (one byte)	The available characters are the same as those of the [User ID] setting parameter								

## 6-6-25. Email Address (Destination) Settings "E-mail Address"

- The email address (destination) settings are displayed to enable you to edit them.
- The columns of the table represent the destination Email addresses, and the rows represent the Email address numbers.
- For AL4000/AH4000 with the communication method, you can edit these settings (refer to the table \* 1 in section 6-1-5).  
\* Refer to the instruction manual of the instrument and the manual for communication interface for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the email address (destination) settings.

[Email Address (Destination) Settings "E-mail Address" Parameter List]

Setting parameter	Function	Remarks
Destination Email Address "Address"	Set the Email destination address using up to 32 characters (one byte)	Available characters (one byte): ABCDEFGHIJKLMNOPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz0123456789+-._@ (refer to section 6-1-2)

## 6-6-26. Email Address (Sending Condition) Settings "E-mail Condition"

- The email address (sending condition) settings are displayed to enable you to edit them.
- For AL4000/AH4000 with the communication method, you can edit these settings (refer to the table \* 1 in section 6-1-5).
- \* Refer to the instruction manual of the instrument and the manual for communication interface for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the email address (sending condition) settings.

[Email Address (Sending Condition) Settings "E-mail Condition" Parameter List]

Setting parameter	Function	Remarks										
Condition Type "Condition"	Select the condition type for sending Email <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>Unused</td><td>None</td></tr> <tr><td>When Alarm Occurred</td><td>Alarm</td></tr> <tr><td>Set Time (Send Measured Value)</td><td>Interval</td></tr> <tr><td>System Event</td><td>Fail</td></tr> </table>	Software screen	Instrument screen	Unused	None	When Alarm Occurred	Alarm	Set Time (Send Measured Value)	Interval	System Event	Fail	
Software screen	Instrument screen											
Unused	None											
When Alarm Occurred	Alarm											
Set Time (Send Measured Value)	Interval											
System Event	Fail											
Sending Destination Start CH, Last CH "Target CH"	Set the start CH and last CH of the target CHs to send Email when an alarm for measured data or a specific CH occurs <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>(Start CH) None</td><td>From *</td></tr> <tr><td>(Start CH) 1 to 24</td><td>From 1 to 24</td></tr> <tr><td>(Last CH) None</td><td>To *</td></tr> <tr><td>(Last CH) 1 to 24</td><td>To 1 to 24</td></tr> </table>	Software screen	Instrument screen	(Start CH) None	From *	(Start CH) 1 to 24	From 1 to 24	(Last CH) None	To *	(Last CH) 1 to 24	To 1 to 24	The number of the displayed channels vary depending on the instrument model.
Software screen	Instrument screen											
(Start CH) None	From *											
(Start CH) 1 to 24	From 1 to 24											
(Last CH) None	To *											
(Last CH) 1 to 24	To 1 to 24											
Send Measured Value Standard Time "Std.TIME"	Set the reference time for sending the measured data <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>00 to 23 (Hour)</td><td>00 to 23 Hour</td></tr> <tr><td>00 to 59 (Minute)</td><td>00 to 59 Min</td></tr> </table>	Software screen	Instrument screen	00 to 23 (Hour)	00 to 23 Hour	00 to 59 (Minute)	00 to 59 Min					
Software screen	Instrument screen											
00 to 23 (Hour)	00 to 23 Hour											
00 to 59 (Minute)	00 to 59 Min											
Interval Hour, Minutes "Interval"	Set the interval for sending the measured data <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>0 to 24 hours</td><td>00 to 24 Hour</td></tr> <tr><td>0 to 59 minute</td><td>00 to 59 Min</td></tr> </table>	Software screen	Instrument screen	0 to 24 hours	00 to 24 Hour	0 to 59 minute	00 to 59 Min					
Software screen	Instrument screen											
0 to 24 hours	00 to 24 Hour											
0 to 59 minute	00 to 59 Min											
Select Destination Email Address "Address No."	Select the destination to send Email based on conditions <table border="1"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>1</td><td>No.1</td></tr> <tr><td>2</td><td>No.2</td></tr> <tr><td>3</td><td>No.3</td></tr> </table>	Software screen	Instrument screen	1	No.1	2	No.2	3	No.3	Select up to three from the destination addresses set in the Email address (destination) by checking their address numbers (refer to section 6-6-25)		
Software screen	Instrument screen											
1	No.1											
2	No.2											
3	No.3											

## 6-6-27. Calendar Timer Settings "Timer"

- The calendar timer settings are displayed to enable you to edit them.
- For AL4000/AH4000, you can edit these settings.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the calendar timer settings.

#### [Calendar Timer Settings "Timer" Parameter List]

Setting parameter	Function	Remarks												
Mode "Mode"	Select the timer type <table border="1"> <tr> <td>Software screen</td><td>Instrument screen</td></tr> <tr> <td>Unused</td><td>None</td></tr> <tr> <td>ON Time</td><td>ON</td></tr> <tr> <td>ON/OFF Time</td><td>ON&amp;OFF</td></tr> </table>	Software screen	Instrument screen	Unused	None	ON Time	ON	ON/OFF Time	ON&OFF					
Software screen	Instrument screen													
Unused	None													
ON Time	ON													
ON/OFF Time	ON&OFF													
ON Date/Time "Timer ON"	Set the date and time when turning ON the alarm output or printing message <table border="1"> <tr> <td>Software screen</td><td>Instrument screen</td></tr> <tr> <td>2000 to 2099 (Year)</td><td>2000 to 2099 Year</td></tr> <tr> <td>1 to- 12 (Month)</td><td>1 to 12 Month</td></tr> <tr> <td>1 to 31 (Day)</td><td>1 to 31 Day</td></tr> <tr> <td>00 to 23 (Hour)</td><td>00 to 23 Hour</td></tr> <tr> <td>00 to 59 (Minute)</td><td>00 to 59 Min</td></tr> </table>	Software screen	Instrument screen	2000 to 2099 (Year)	2000 to 2099 Year	1 to- 12 (Month)	1 to 12 Month	1 to 31 (Day)	1 to 31 Day	00 to 23 (Hour)	00 to 23 Hour	00 to 59 (Minute)	00 to 59 Min	
Software screen	Instrument screen													
2000 to 2099 (Year)	2000 to 2099 Year													
1 to- 12 (Month)	1 to 12 Month													
1 to 31 (Day)	1 to 31 Day													
00 to 23 (Hour)	00 to 23 Hour													
00 to 59 (Minute)	00 to 59 Min													
OFF Date/Time "Timer OFF"	Set the date and time when turning OFF the alarm output The displays on the software and instrument screens are the same as those of the [On Date/Time] setting parameter													
Output No. "Relay No."	Specify the output destination (relay No.) when the timer is ON <table border="1"> <tr> <td>Software screen</td><td>Instrument screen</td></tr> <tr> <td>None</td><td>-</td></tr> <tr> <td>1 to 24</td><td>1 to 24</td></tr> <tr> <td>Dummy Output</td><td>99</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 24	1 to 24	Dummy Output	99	The number vary depending on the instrument model.				
Software screen	Instrument screen													
None	-													
1 to 24	1 to 24													
Dummy Output	99													
Output Mode "And/Or"	Select the connection method to the output destination when the timer is ON <table border="1"> <tr> <td>Software screen</td><td>Instrument screen</td></tr> <tr> <td>OR</td><td>Or</td></tr> <tr> <td>AND</td><td>And</td></tr> </table>	Software screen	Instrument screen	OR	Or	AND	And							
Software screen	Instrument screen													
OR	Or													
AND	And													
Message No. "Message No."	Specify the message No. to be printed when the timer is turned on <table border="1"> <tr> <td>Software screen</td><td>Instrument screen</td></tr> <tr> <td>None</td><td>-</td></tr> <tr> <td>1 to 20</td><td>1 to 20</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 20	1 to 20							
Software screen	Instrument screen													
None	-													
1 to 20	1 to 20													

## 2. Copy and paste operations for calendar timer setting

For the calendar timer setting, you can copy and paste parameters per timer number (parameters belonging to one timer number).

### <How to copy/paste>


#### (1) Select the copy source

- Click to select a timer number or any column to copy from.
- \* You can copy parameters per one timer number. That means, you cannot select multiple timer numbers to copy the parameters at a time.




#### (2) Click the [Copy] button

- Click the [Copy] button from the tool bar to copy the selected parameters.




#### (3) Select the paste destination

- Click to select a timer number or any column to paste to.
- \* You can paste the parameters to one timer number. That means, you cannot select multiple timer numbers to paste the parameters at a time.



#### (4) Click the [Paste] button

- Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one timer number.

## 6-6-28. External Drive Settings "Dig Inp"

- The settings for the external drive are displayed in the table format to enable you to edit them.
- The columns of the table represent the functions, and the rows represent the external drive numbers.
- For AL4000/AH4000 or KL4000/KH4000 with the alarm output + external drive method, you can edit these settings (refer to the table \* 1 in section 6-1-5).
- The number of the displayed external drive numbers vary depending on the instrument model.
- \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the external drive settings.

#### [External Drive Settings "Dig Inp" Parameter List]

Setting parameter	Function		Remarks
Function "Mode"	Allocate functions to the given external drive terminal numbers		<p><b>To select [Chart Speed]</b> The external drive No. 1 and No. 2 must be set to "Chart Speed". * If both the external drives No.1 and No.2 are not set, the chart speed selection does not work.</p> <p><b>To select [Message (1,2)]</b> The external drive No. 1 and No. 2 must be set to "Message (1,2)". * If both the external drives No.1 and No.2 are not set, the message (1,2) selection does not work.</p> <p><b>To select [Message (1,2,3,4,5)]</b> The external drive No. 1 to No. 4 must be set to "Message (1,2,3,4,5)". * If all of the external drives No.1 to No.4 are not set, the message (1,2,3,4,5) selection does not work.</p>
	Software screen	Instrument screen	
	Unused	None	
	Chart Speed*	ChartSpeed	
	Message (1,2)*	Message 1, 2	
	Message (1,2,3,4,5)*	Message 1 to 5	
	Data Printing	DataPrint	
	List 1 Printing - List 3 Printing	ListPrint 1 to ListPrint 3	
	Integration Reset (Batch)	INT-Reset(All)	
	Message 1 Printing - Message 20s Printing	Message 1 to Message 20	

## 6-6-29. Operation Recording Settings "Ope.Rec"

- The settings for the external drive are displayed in the table format to enable you to edit them.
- The columns of the table present the setting parameter types, and the rows present the external drive numbers.
- For AL4000/AH4000 with the alarm output + external drive method, you can edit these settings (refer to the table \* 1 in section 6-1-5).
- The number of the displayed external drive numbers vary depending on the instrument model.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the operation recording settings.

#### [Operation Recording Settings "Ope.Rec" Parameter List]

Setting parameter	Function	Remarks														
Operation Recording "ON/OFF"	Specify whether the operation recording is turned on or off <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>ON</td> <td>ON</td> </tr> </table>	Software screen	Instrument screen	OFF	OFF	ON	ON									
Software screen	Instrument screen															
OFF	OFF															
ON	ON															
Recording Position (%) "Position"	Set the recording position for input OFF status in proportion to the chart zero span (%) <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>0 to 90</td> <td>0 to 90</td> </tr> </table>	Software screen	Instrument screen	0 to 90	0 to 90											
Software screen	Instrument screen															
0 to 90	0 to 90															
Chart Width (Mm) "Width"	Set the recording position for input ON status by the chart zero span (millimeters) from the input OFF recording position <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>1 to 10</td> <td>1 to 10</td> </tr> </table>	Software screen	Instrument screen	1 to 10	1 to 10											
Software screen	Instrument screen															
1 to 10	1 to 10															
Color "Color"	Select the color for recording <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Red</td> <td>Red</td> </tr> <tr> <td>Black</td> <td>Black</td> </tr> <tr> <td>Blue</td> <td>Blue</td> </tr> <tr> <td>Green</td> <td>Green</td> </tr> <tr> <td>Brown</td> <td>Brown</td> </tr> <tr> <td>Purple</td> <td>Purple</td> </tr> </table>	Software screen	Instrument screen	Red	Red	Black	Black	Blue	Blue	Green	Green	Brown	Brown	Purple	Purple	
Software screen	Instrument screen															
Red	Red															
Black	Black															
Blue	Blue															
Green	Green															
Brown	Brown															
Purple	Purple															

## 2. Copy and paste operations for operation recording setting


For the operation recording setting, you can copy and paste parameters per external drive number (parameters belonging to one external drive number).

### <How to copy/paste>

#### (1) Select the copy source


Click to select an external drive number or any column to copy from.

- \* You can copy parameters per one external drive number. That means, you cannot select multiple external drive numbers to copy the parameters at a time.



#### (2) Click the [Copy] button


Click the [Copy] button from the tool bar to copy the selected parameters.



#### (3) Select the paste destination


Click to select an external drive number or any column to paste to.

- \* You can paste the parameters to one external drive number. That means, you cannot select multiple external drive numbers to paste the parameters at a time.



#### (4) Click the [Paste] button

Click the [Paste] button from the tool bar to paste the parameters to the selected location.




#### Remarks → "Keeping copied data" and "Copy/paste unit"

- The copied parameters are kept after a paste operation until the [Copy] button is clicked the next time. Note that, if you move to another setting item in the edit panel after a copy operation, the copied parameters are lost.
- You cannot copy or paste per setting parameter. The copy or paste operation can be used by one external drive number.

## 6-6-30. Failout Settings "FailOut"

- The settings for the failout are displayed in the table format to enable you to edit them.
- The columns of the table represent the setting parameter types, and the rows represent the event types for failout.
- For AL4000/AH4000 or KL4000/KH4000, you can edit these settings (for KL4000/KH4000, the settings of "Low Remaining SD", "LCD Display", and "Email" cannot be changed).
- \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the failout settings.


#### [Failout Settings "FailOut" Parameter List]

Setting parameter	Function	Remarks										
Chart End "Chart End"	<p>Set the alarm action at detection of chart end Use the check boxes for selection</p> <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>LCD Display</td> <td>LCD</td> </tr> <tr> <td>LED Display *</td> <td>LED *</td> </tr> <tr> <td>Email *</td> <td>E-mail *</td> </tr> <tr> <td>Relay output</td> <td>Relay</td> </tr> </table>	Software screen	Instrument screen	LCD Display	LCD	LED Display *	LED *	Email *	E-mail *	Relay output	Relay	<p>Check box operation:  <input checked="" type="checkbox"/> Checked...Display  <input type="checkbox"/> Unchecked...Do not display</p> <p>* For KL4000/KH4000, the settings cannot be changed.</p>
Software screen	Instrument screen											
LCD Display	LCD											
LED Display *	LED *											
Email *	E-mail *											
Relay output	Relay											
Input Disconnected "Burn"	<p>Set the alarm action at detection of input disconnection Use the check boxes for selection</p> <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>LCD Display</td> <td>LCD</td> </tr> <tr> <td>LED Display *</td> <td>LED *</td> </tr> <tr> <td>Email *</td> <td>E-mail *</td> </tr> <tr> <td>Relay output</td> <td>Relay</td> </tr> </table>	Software screen	Instrument screen	LCD Display	LCD	LED Display *	LED *	Email *	E-mail *	Relay output	Relay	
Software screen	Instrument screen											
LCD Display	LCD											
LED Display *	LED *											
Email *	E-mail *											
Relay output	Relay											
Low Remaining SD Card Memory "SD Card"*	<p>Set the alarm action at detection of SD card low capacity Use the check boxes for selection</p> <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>LCD Display *</td> <td>LCD *</td> </tr> <tr> <td>LED Display *</td> <td>LED *</td> </tr> <tr> <td>Email *</td> <td>E-mail *</td> </tr> <tr> <td>Relay output *</td> <td>Relay *</td> </tr> </table>	Software screen	Instrument screen	LCD Display *	LCD *	LED Display *	LED *	Email *	E-mail *	Relay output *	Relay *	
Software screen	Instrument screen											
LCD Display *	LCD *											
LED Display *	LED *											
Email *	E-mail *											
Relay output *	Relay *											

Low Remaining Battery Power For Backup "Battery"	<p>Set the alarm action at detection of backup battery low level Use the check boxes for selection</p> <table border="1" data-bbox="473 204 965 354"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>LCD Display</td><td>LCD</td></tr> <tr><td>LED Display *</td><td>LED *</td></tr> <tr><td>Email *</td><td>E-mail *</td></tr> <tr><td>Relay output</td><td>Relay</td></tr> </table>	Software screen	Instrument screen	LCD Display	LCD	LED Display *	LED *	Email *	E-mail *	Relay output	Relay	<p>Check box operation:  <input checked="" type="checkbox"/> Checked...Display  <input type="checkbox"/> Unchecked...Do not display</p> <p>* For KL4000/KH4000, the settings cannot be changed.</p>
Software screen	Instrument screen											
LCD Display	LCD											
LED Display *	LED *											
Email *	E-mail *											
Relay output	Relay											
Main Body Error "System Error"	<p>Set the alarm action at detection of main body error Use the check boxes for selection</p> <table border="1" data-bbox="473 408 965 559"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>LCD Display</td><td>LCD</td></tr> <tr><td>LED Display *</td><td>LED *</td></tr> <tr><td>Email *</td><td>E-mail *</td></tr> <tr><td>Relay output</td><td>Relay</td></tr> </table>	Software screen	Instrument screen	LCD Display	LCD	LED Display *	LED *	Email *	E-mail *	Relay output	Relay	
Software screen	Instrument screen											
LCD Display	LCD											
LED Display *	LED *											
Email *	E-mail *											
Relay output	Relay											
Set Relay Output Output No. "Relay No."	<ul style="list-style-type: none"> <li>Set the alarm output destination No. at detection of chart end</li> <li>Set the alarm output destination No. at detection of input disconnection</li> <li>Set the alarm output destination No. at detection of SD card low capacity</li> <li>Set the alarm output destination No. at detection of backup battery low level</li> <li>Set the alarm output destination No. at detection of main body error</li> </ul> <table border="1" data-bbox="473 792 965 916"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>None</td><td>-</td></tr> <tr><td>1 to 24</td><td>1 to 24</td></tr> <tr><td>Dummy Output</td><td>99</td></tr> </table>	Software screen	Instrument screen	None	-	1 to 24	1 to 24	Dummy Output	99	The number vary depending on the instrument model.		
Software screen	Instrument screen											
None	-											
1 to 24	1 to 24											
Dummy Output	99											
Set Relay Output Output Mode "And/Or"	<ul style="list-style-type: none"> <li>Select the connection method of the alarm output destination at detection of chart end</li> <li>Select the connection method of the alarm output destination at detection of input disconnection</li> <li>Select the connection method of the alarm output destination at detection of SD card low capacity</li> <li>Select the connection method of the alarm output destination at detection of backup battery low level</li> <li>Select the connection method of the alarm output destination at detection of main body error</li> </ul> <table border="1" data-bbox="473 1172 965 1273"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>OR</td><td>Or</td></tr> <tr><td>AND</td><td>And</td></tr> </table>	Software screen	Instrument screen	OR	Or	AND	And					
Software screen	Instrument screen											
OR	Or											
AND	And											

## 6-6-31. Display Settings "Display"

- The display settings are displayed to enable you to edit them.
- For AL4000/AH4000, you can edit these settings.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting

You can configure the following parameters in the display settings.


**[Display Settings "Display" Parameter List]**

Setting parameter	Function	Remarks																
Display Mode "Display Mode"	Select the number of CHs and the information displayed simultaneously on a single screen <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>1ch Expand</td> <td>01CH</td> </tr> <tr> <td>1ch + Bar</td> <td>01CH + Bar</td> </tr> <tr> <td>6ch Batch</td> <td>06CH</td> </tr> <tr> <td>12ch Batch *</td> <td>12CH *</td> </tr> <tr> <td>24ch Batch *</td> <td>24CH *</td> </tr> </table>	Software screen	Instrument screen	1ch Expand	01CH	1ch + Bar	01CH + Bar	6ch Batch	06CH	12ch Batch *	12CH *	24ch Batch *	24CH *	* Available display modes vary depending on the instrument model.				
Software screen	Instrument screen																	
1ch Expand	01CH																	
1ch + Bar	01CH + Bar																	
6ch Batch	06CH																	
12ch Batch *	12CH *																	
24ch Batch *	24CH *																	
Unit/Tag "Unit/Tag"	Select whether unit or tag you want to display <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Unit</td> <td>Unit</td> </tr> <tr> <td>Tag</td> <td>Tag</td> </tr> </table>	Software screen	Instrument screen	Unit	Unit	Tag	Tag											
Software screen	Instrument screen																	
Unit	Unit																	
Tag	Tag																	
Manual/Automatic Switching Of Measured CH Update "Auto/Const"	Select either manual (with keys) or automatic (with update interval) for displayed CH update <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Manual</td> <td>Const</td> </tr> <tr> <td>Automatic</td> <td>Auto</td> </tr> </table>	Software screen	Instrument screen	Manual	Const	Automatic	Auto											
Software screen	Instrument screen																	
Manual	Const																	
Automatic	Auto																	
Display CH Update Interval "CH-Update Interval"	Set the update interval of the displayed CHs <table border="1"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>Synchronized With Dots</td> <td>Synchro</td> </tr> <tr> <td>1 Second</td> <td>1sec</td> </tr> <tr> <td>2 Seconds</td> <td>2sec</td> </tr> <tr> <td>3 Seconds</td> <td>3sec</td> </tr> <tr> <td>5 Seconds</td> <td>5sec</td> </tr> <tr> <td>10 Seconds</td> <td>10sec</td> </tr> <tr> <td>30 Seconds</td> <td>30sec</td> </tr> </table>	Software screen	Instrument screen	Synchronized With Dots	Synchro	1 Second	1sec	2 Seconds	2sec	3 Seconds	3sec	5 Seconds	5sec	10 Seconds	10sec	30 Seconds	30sec	
Software screen	Instrument screen																	
Synchronized With Dots	Synchro																	
1 Second	1sec																	
2 Seconds	2sec																	
3 Seconds	3sec																	
5 Seconds	5sec																	
10 Seconds	10sec																	
30 Seconds	30sec																	

Use Of Display Order Setting "Display-order"	<p>Select whether to display the measured values in the CH No. order (OFF) or in an arbitrary order (ON)</p> <table border="1" data-bbox="489 204 981 294"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>Stop</td><td>OFF</td></tr> <tr><td>Do</td><td>ON</td></tr> </table>	Software screen	Instrument screen	Stop	OFF	Do	ON							
Software screen	Instrument screen													
Stop	OFF													
Do	ON													
Backlight "Display Backlight"	<p>Select ON or AUTO for the LCD backlight With AUTO selected, the LCD backlight is turned off after no operations for three minutes</p> <table border="1" data-bbox="489 377 981 467"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>Always On</td><td>ON</td></tr> <tr><td>Automatic</td><td>AUTO</td></tr> </table>	Software screen	Instrument screen	Always On	ON	Automatic	AUTO							
Software screen	Instrument screen													
Always On	ON													
Automatic	AUTO													
Brightness "Display Backlight Level"	<p>Select the brightness of the backlight</p> <table border="1" data-bbox="489 489 981 676"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>1 (Dark)</td><td>1</td></tr> <tr><td>2</td><td>2</td></tr> <tr><td>3</td><td>3</td></tr> <tr><td>4</td><td>4</td></tr> <tr><td>5 (Bright)</td><td>5</td></tr> </table>	Software screen	Instrument screen	1 (Dark)	1	2	2	3	3	4	4	5 (Bright)	5	Degree of brightness: 1 < 5 (Dark) (Bright)
Software screen	Instrument screen													
1 (Dark)	1													
2	2													
3	3													
4	4													
5 (Bright)	5													
Record Lighting "Chart Illumination"	<p>Select ON, OFF, or AUTO for the chart illumination With AUTO selected, the record lighting is turned off after no operations for three minutes</p> <table border="1" data-bbox="489 759 981 869"> <tr><td>Software screen</td><td>Instrument screen</td></tr> <tr><td>Always On</td><td>ON</td></tr> <tr><td>OFF</td><td>OFF</td></tr> <tr><td>Automatic</td><td>AUTO</td></tr> </table>	Software screen	Instrument screen	Always On	ON	OFF	OFF	Automatic	AUTO					
Software screen	Instrument screen													
Always On	ON													
OFF	OFF													
Automatic	AUTO													

## 6-6-32. Date/Time Settings "Date"

- The date/time settings are displayed to enable you to edit them.
- For AL4000/AH4000 or KL4000/KH4000 and online, you can edit these settings.  
 \* Refer to the instruction manual of the instrument for more details on the settings.



### 1. Parameter setting


You can configure the following parameters in the date/time settings.

[Date/Time Settings "Date" Parameter List]

Setting parameter	Function		Remarks
Date/Time of PC	Display the date/time of the PC		Click the [Synchronize With PC] button to set the date/time of PC at that time to the connected instrument.
Setting Date/Time	"Year"	Set the year Software screen 2000 to 2099	After entering the date/time, click the [Setting] button to set the specified date/time to the connected instrument.
	"Month"	Set the month Software screen 1 to 12	
	"Day"	Set the day Software screen 1 to 31	
	"Hour"	Set the hour Software screen 00 to 23	
	"Min"	Set the minute Software screen 00 to 59	
	"Sec"	Set the second Software screen 00 to 59	

### 6-6-33. System Settings "System"

- The system settings are displayed to enable you to edit them.
- For AL4000/AH4000 and KL4000/KH4000, you can edit these settings.  
\* Refer to the instruction manual of the instrument for more details on the settings.



#### 1. Parameter setting

You can configure the following parameters in the system settings.


##### [System Settings "System" Parameter List]

Setting parameter	Function	Remarks
Key Lock "Key Lock"	Disable the keys to change settings Use the check boxes for selection * If you enable [Key Lock], the settings of all items cannot be changed on the instrument. However, you can see the settings.	Check box operation: <input checked="" type="checkbox"/> Checked...Enable key lock <input type="checkbox"/> Unchecked...Disable key lock  <u>When in online, the setting is sent to the instrument when the check box <input checked="" type="checkbox"/> is checked.</u>

- \* On the instrument screen, the following setting parameters are displayed in addition to the "Key Lock" parameter:  
"Initialize" for clearing the memory, "Adjust of Rec position" for disabling/enabling the zero or span adjustment for dot printing position, and "Input Correction" for disabling/enabling the input correction setting. On the software screen, only "Key Lock" is displayed.

## 6-6-34. Format Display

- The [Format] settings are displayed.
- For AL4000/AH4000 and KL4000/KH4000, you can display these settings.



### 1. Parameter setting

The Format parameter displays the following.


#### [Format Display Parameter List]

Setting parameter	Function	Remarks
Format "TYPE"	Display the model code of the instrument * "-" (hyphen) is excluded	* You can check the model code in "SysInfo" on the instrument.

\* On the instrument screen, the system information display "SysInfo" shows the model code "TYPE" as well as the following setting parameters: the serial number of the instrument "No.", the MAC address of the instrument with Ethernet option "MAC Adr.", the additional information "SP", the status information of other system error "System Value", the printer software version "P", the application software version "A" and "E", the preamplifier 1 software version "I1", and the preamplifier 2 software version "I2". On the software screen, only "Format" is displayed.

### 6-6-35. Display Order Settings "D.Order"

- The settings for the display order are displayed in the table format to enable you to edit them.
- The columns of the table represent the channel numbers, and the rows represent the display order numbers.
- For AL4000/AH4000, you can edit these settings.
- The number of the displayed channels vary depending on the instrument model.  
\* Refer to the instruction manual of the instrument for more details on the settings.



#### 1. Parameter setting


You can configure the following parameters in the display order settings.

#### [Display Order Settings "D.Order" Parameter List]

Setting parameter	Function	Remarks						
CH "CH No."	Set the CH No. to be updated (displayed) <table border="1" style="margin-top: 5px;"> <tr> <td>Software screen</td> <td>Instrument screen</td> </tr> <tr> <td>None</td> <td>-</td> </tr> <tr> <td>1 to 24</td> <td>1 to 24</td> </tr> </table>	Software screen	Instrument screen	None	-	1 to 24	1 to 24	None: Skipped when the 1CH display is set on the instrument, or blank when the multiple CH display is set  The number of the displayed channels varies depending on the instrument model.
Software screen	Instrument screen							
None	-							
1 to 24	1 to 24							

### 6-6-36. Soft Dip Switch Settings

- The [Soft Dip Switch] settings are displayed.
- For AL4000/AH4000 and KL4000/KH4000, you can display these settings.



## 6-7. Operation of Help Screen

On any screen, click the [Help] button to show the instruction manual. Refer to it as requirement.


### <Procedure>

#### (1) Open the Parameter Setting Menu screen or the Parameter Setting screen


Open the Parameter Setting Menu screen (refer to section 6-2) or the Parameter Setting screen (refer to section 6-6).

#### (2) Click the [Help] button

Click the [Help] button on the Parameter Setting Menu screen or the Parameter Setting screen.



#### • [Help] button on the Parameter Setting screen



#### (3) Display the instruction manual

The instruction manual is displayed in Internet Explorer.

## 6-8. Operation of Version Check Screen

On any screen, click the [Version] button to show the version of this software.  
When contacting us about the software, please provide this version number.

### <Procedure>


#### (1) Open the Parameter Setting Menu screen or the Parameter Setting screen

Open the Parameter Setting Menu screen (refer to section 6-2) or the Parameter Setting screen (refer to section 6-6).


#### (2) Click the [Version] button

Click the [Version] button on the Parameter Setting Menu screen or the Parameter Setting screen.

- [Version] button on the Parameter Setting Menu screen



- [Version] button on the Parameter Setting screen



#### (3) Display the version information of the setting software

The Version Information Of Setting Software screen is displayed. When contacting us, please provide the version number.



# 7. Parameter Switching Tool

With the parameter switching tool, you can connect an old model hybrid recorder<sup>\*1</sup> to your PC via engineering cable to create a setting file for new model hybrid recorder<sup>\*2</sup> (multi-point type only).

<sup>\*1</sup>: Multi-point type AL3000/AH3000 or old BL/old BH ("old model instrument" for short).

<sup>\*2</sup>: Multi-point type AL4000/AH4000 or KL4000/KH4000 ("new model instrument" for short).

The table below shows the possible combinations for the parameter switching tool.

## [Switchable Combinations]


Old model instrument	Switching	New model instrument
AL3000 (multi-point type)	→	AL4000 (multi-point type)
AH3000 (multi-point type)	→	AH4000 (multi-point type)
Old BL (multi-point type)	→	KL4000 (multi-point type)
Old BH (multi-point type)	→	KH4000 (multi-point type)

\* The contents of "Attention", "Notices", "Trademark", "Request", and "Before use" are the same as those of the parameter setting software (refer to section 1).

Please read them carefully before using the tool.

## 7-1. System Configuration

To use the software, the PC and the instrument should be connected one-to-one with an engineering cable. Connect a new model instrument to the PC before writing the read parameters to the new model instrument (refer to section 2-1).



## 7-2. Operating Condition of Software

This is the same as for the parameter setting software (refer to section 2-2).

Besides, to use the parameter switching tool, the parameter setting software must have been installed. Install the parameter setting software before using the parameter switching tool (refer to section 3-1).

## 7-3. Installation

### 7-3-1. New Installation

Install the software from the CD-ROM to the PC before using it.

Use the following procedure for installation.

#### <Procedure>


##### (1) Insert the CD-ROM

Start Windows, and then insert the CD-ROM into the CD-ROM drive. The menu screen is started automatically.

\* If the menu screen is not started automatically, start "asmenu.exe" in the CD-ROM.

##### (2) Click the [Parameter Migration Tool] button

Click the [Parameter Migration Tool] button on the Hybrid Recorder Software Install Menu screen.



##### (3) Accept the license terms (If .NET Framework 3.5 is already installed, go to step (4))


When the Microsoft Software Supplemental

License Terms (.NET Framework 3.5) is displayed, read the contents carefully.

If you accept them, click the [Accept] button. This will start the installation of .NET Framework 3.5 (this process may take several minutes).

If you click the [Don't Accept] button, you cannot use this software.

\* The license terms may not be displayed when .NET Framework 3.5 is already installed.




**(4) Click the [Next] button**

The Parameter Migration Tool Setup Wizard screen appears. Click the [Next] button.




**(5) Click the [Next] button**

On the Confirm Installation screen, click the [Next] button.




**(6) Start the installation**

The installation is started. The screen indicating the progress of installation appears. Wait until the installation is completed.



## (7) Complete the installation

The installation complete screen appears. Click the [Close] button to finish.



### 7-3-2. Installation at Upgrade

The parameter switching tool is sometimes upgraded to add newly supported instruments or to fix issues.  
Use the following procedure for version upgrade.

#### <Procedure>

- (1) Uninstall the current version (refer to section 7-4).
- (2) Install the new version (refer to section 7-3-1).

#### Remarks → About uninstallation for version upgrade

- The uninstallation should be done from the [Program and Features] dialog box in Windows as described in "7-4. Uninstallation".  
You cannot complete the uninstallation by simply deleting the files (moving them to the "Recycle Bin").
- Do not delete the folder during an uninstallation for version upgrade.


## 7-4. Uninstallation

This section describes how to delete the parameter switching tool from the hard disk.  
Exit all programs related to the parameter switching tool before starting the uninstallation.

### <Procedure>

#### (1) Open the Control Panel

Click [Start] → [Control Panel].




#### (2) Click [Uninstall a program]

When the Control Panel is displayed, click [Uninstall a program].




#### (3) Delete [Parameter Migration Tool]

Select [Parameter Migration Tool] from the list displayed in [Uninstall or change a program], and then click [Uninstall].



**(4) Click [Yes]**


On the Program and Feature screen, click [Yes].



**(5) Start uninstallation**

The uninstallation is started. The screen indicating the progress of uninstallation appears. Wait until the uninstallation is completed. When the uninstallation is completed, the screen shown right is closed automatically.

- \* At this point, the folder related to the software still remains. To completely delete the software, delete the installation folder "ParameterMigration" using the Windows Explorer. The location of the folder is shown in the table below.



**[Location of the folder related to the software]**

OS	Location of folder
Windows XP	C:\Documents and Settings\[user name]\Application Data\CHINO\ParameterMigration\
Windows Vista, Windows 7	C:\Users\[user name]\AppData\Roaming\CHINO\ParameterMigration\

**Remarks**

**About uninstallation for version upgrade**

- You cannot complete the uninstallation by simply deleting the files (moving them to the "Recycle Bin").
- Do not delete the folder during an uninstallation for version upgrade.

## 7-5. Startup and Exit of Switching Tool


### 7-5-1. Startup

This section describes how to start the parameter switching tool.

#### <Procedure>


##### (1) Display all programs

Click [Start] → [All Programs].




##### (2) Click [Parameter Migration Tool]

Next, click [CHINO] → [Configuration&Migration] → [Parameter Migration Tool] to start the software.



##### (3) Open the Parameter Switching Tool screen

The Parameter Switching Tool screen appears. Perform the switching operation (refer to section 7-6).




### 7-5-2. Exit

This section describes how to exit the parameter switching tool.

#### <Procedure>

##### (1) Click the [Exit] or [x] button on the Parameter Switching Tool screen

Click the [Exit] or [x] button on the Parameter Switching Tool screen to exit the parameter switching tool.



## 7-6. How to Operate

### 7-6-1. Parameter Reading from Old Model Instrument

#### <Procedure>

##### (1) Match the communication setting in PC and old model instrument

Confirm that the PC is connected to the old model instrument with engineering cable, and then check the communication setting of the old model instrument.

- **For AL3000/AH3000**

Switch the communication setting of the instrument to COM.

- **For old BL/old BH**


Skip this operation.

##### (2) Start the parameter switching tool

When you start the parameter switching tool, the Parameter Switching Tool screen appears (refer to section 7-5-1).

##### (3) Click the [Serial Port Setting] button

Click the [Serial Port Setting] button on the Parameter Switching Tool screen.




##### (4) Configure the serial port setting

When the Serial Port Setting screen appears, select the port of the connected old model instrument in [Port].


Confirm that [Speed], [Data Bit], [Parity], and [Stop Bit] are set as shown in the table below, and then click the [OK] button.

Programming parameter	Setting value
Speed	9600
Data bit	8
Parity	None
Stop Bit	1



##### (5) Click the [Start Switching] button

Click the [Start Switching] button on the Parameter Switching Tool screen.



## (6) Specify the files


When the message "Select an XML file to open" is displayed, select a file below depending on the connected instrument, and then click the [Open] button.

- **When the connected instrument is AL3000/AH3000**

File name: BlockTemplateAH\_D.xml

- **When the connected instrument is old BL/old BH**


File name: BlockTemplateKH\_D.xml



## (7) Save with a name


When the message "Specify a file name to output" is displayed, enter the file name in [File Name], and then click the [Save] button.

- \* The destination is set to "My Documents" by default when the screen shown on the right figure is displayed.



## (8) Click the [OK] button

The Ended Processing screen is displayed, click the [OK] button.



## (9) Exit the switching tool

Click the [Exit] or [x] button on the Parameter Switching Tool screen to exit the parameter switching tool (refer to section 7-5-2).

## 7-6-2. Parameter Writing to New Model Instrument

### <Procedure>

#### (1) Start the parameter setting software

When you start the parameter setting software, the Parameter Setting Menu screen is displayed (refer to section 5-1).

#### (2) Select online or offline (new)

Specify whether to write the read parameters online or offline (new) after confirming and editing them in the parameter setting software.

- \* Select [Online] or [Offline (New)], considering the range of values that can be handled by the parameter setting software (refer to section 4).

- To write online after confirmation**

Confirm that the PC is connected to the new model instrument with engineering cable, and then select [Online] (refer to section 6-2-1).

- To save as a new file after confirmation to write using SD card**


Select [Offline (New)] (refer to section 6-2-3).

- \* Do not use the [Offline (File)] option.

#### (3) Get the parameters to switch

Display the parameters read from the old model instrument. Click the [Open] button from the tool bar on the Parameter Setting screen to open the file containing the read parameters (refer to section 6-6).

- \* If you forget the destination file, check the [My Documents] folder.



#### (4) Confirm/Edit in the Parameter Setting screen

On the Parameter Setting screen, the switched parameters are displayed. Confirm and edit the switched parameters (refer to section 6).

Parameter	Type	Range	Scale	Unit	Setting
CH1	10 V-500 - External	None	-50.00	50.00	2
CH2	10 V-500 - External	None	-50.00	50.00	2
CH3	10 V-500 - External	None	-50.00	50.00	2
CH4	10 V-500 - External	None	-50.00	50.00	2
CH5	10 V-500 - External	None	-50.00	50.00	2
CH6	10 V-500 - External	None	-50.00	50.00	2
CH7	10 V-500 - External	None	-50.00	50.00	2
CH8	10 V-500 - External	None	-50.00	50.00	2
CH9	10 V-500 - External	None	-50.00	50.00	2
CH10	10 V-500 - External	None	-50.00	50.00	2
CH11	10 V-500 - External	None	-50.00	50.00	2
CH12	10 V-500 - External	None	-50.00	50.00	2
CH13	10 V-500 - External	None	-50.00	50.00	2
CH14	10 V-500 - External	None	-50.00	50.00	2
CH15	10 V-500 - External	None	-50.00	50.00	2
CH16	10 V-500 - External	None	-50.00	50.00	2
CH17	10 V-500 - External	None	-50.00	50.00	2
CH18	10 V-500 - External	None	-50.00	50.00	2
CH19	10 V-500 - External	None	-50.00	50.00	2
DH1	10 V-500 - External	None	-50.00	50.00	2
DH2	10 V-500 - External	None	-50.00	50.00	2
DH3	10 V-500 - External	None	-50.00	50.00	2
DH4	10 V-500 - External	None	-50.00	50.00	2
DH5	10 V-500 - External	None	-50.00	50.00	2
DH6	10 V-500 - External	None	-50.00	50.00	2
DH7	10 V-500 - External	None	-50.00	50.00	2
DH8	10 V-500 - External	None	-50.00	50.00	2
DH9	10 V-500 - External	None	-50.00	50.00	2
DH10	10 V-500 - External	None	-50.00	50.00	2
DH11	10 V-500 - External	None	-50.00	50.00	2
DH12	10 V-500 - External	None	-50.00	50.00	2
DH13	10 V-500 - External	None	-50.00	50.00	2
DH14	10 V-500 - External	None	-50.00	50.00	2
DH15	10 V-500 - External	None	-50.00	50.00	2
DH16	10 V-500 - External	None	-50.00	50.00	2
DH17	10 V-500 - External	None	-50.00	50.00	2
DH18	10 V-500 - External	None	-50.00	50.00	2
DH19	10 V-500 - External	None	-50.00	50.00	2
DH20	10 V-500 - External	None	-50.00	50.00	2
DH21	10 V-500 - External	None	-50.00	50.00	2
DH22	10 V-500 - External	None	-50.00	50.00	2
DH23	10 V-500 - External	None	-50.00	50.00	2
DH24	10 V-500 - External	None	-50.00	50.00	2


**Remarks** Confirmation of the switched file

The switching tool cannot convert some parameters (refer to section 7-7). After switching the parameters, be sure to open the switched file in the setting software to confirm and edit the parameters.

## (5) Store and write setting parameters

Store the parameter setting parameters that you confirmed and edited to a file or write them to the new instrument (refer to section 6-6).

From the tool bar of the Parameter Setting screen, click the [Save] button to save the parameters to a file, or the [Parameter Writing] button to write to a new instrument (refer to section 4).



## (6) Exit the setting software

Close the Parameter Setting screen, then close the Parameter Setting Menu screen (refer to section 5-2).

## 7-7. Parameter Switching

This section presents the parameters that can be switched from an old model to a new model instrument.

### 7-7-1. Switchable Parameter Types

The table below shows the switchable parameter types.

[Switchable Parameter List]

Old model instrument (AL3000/AH3000, old BL/old BH)		Switching	New model instrument (AL4000/AH4000, KL4000/KH4000)	
Category	Parameter		Category	Parameter
Range setting	Range number, Range setting ON/OFF	Range	Input Type	
Range setting	Range setting ON/OFF	Range	RJ	
Range setting	Range setting value MIN	Range	Scale Minimum	
Range setting	Range setting value MAX	Range	Scale Maximum	
Range setting	Range setting value MIN, Range setting value MAX	Range	Range Decimal Location	
Burnout	Burnout setting data	Range	Burnout	
Scale setting	Scale setting value MIN	Range	Scale Lower Limit	
Scale setting	Scale setting value MAX	Range	Scale Upper Limit	
Scale setting	Scale setting value MIN, Scale setting value MAX	Range	Scale Decimal Location	
Unit setting	Unit setting value	Range	Unit	
Tag setting	Tag setting value	Range	Tag	
(None)	(None)	* 1	Range	Chart Recording Lower Limit * 1
(None)	(None)	* 1	Range	Chart Recording Upper Limit * 1
(None)	(None)	* 1	Range	Chart Recording Decimal Location * 1
Alarm settings	alarm type	Alarm (each CH)	Type	
Alarm settings	Alarm judgment value	Alarm (each CH)	Alarm Value	
Alarm settings	For optional alarm	Alarm (each CH)	Comparison CH	
Alarm settings	For optional alarm	Alarm (each CH)	Rate-of-Change Standard Time (sec.)	
Alarm settings	Alarm output relay number	Alarm (each CH)	Output No.	
Alarm settings	Alarm output type	Alarm (each CH)	Output Mode	
Chart setting	Speed setting value	Chart Speed	Chart Speed 1	
Chart setting	Speed setting value	Chart Speed	Chart Speed 2	
Chart setting	Speed setting value	Chart Speed	Chart Speed 3	

\* 1: The upper/lower limit values and decimal point position of chart recording will be converted to appropriate scale setting values depending on the input type.

## 7-7-2. Input Type Switching

Input types are handled as follows because they are different between new and old model instruments:

- If the input type number and input range\* are the same between the new and old model instruments, the input type is switched without any change.
- If the input type is the same but the input range\* is different between the new and old model instruments, the input type is converted to an input type that fits to that input range\* (marked as "\* 1" in the table below). However, the input range\* of the old model instrument is switched without any change.
- Input types that exist in the old model instrument but not in the new model instrument are converted to "Unused" (marked as "\* 2" in the table below). Set these input types in the parameter setting software.

\*Input range: The upper/lower limit values and decimal point position of the scale and range.

### Remarks Confirmation of the switched file

After switching the parameters, be sure to open the switched file in the setting software to confirm and edit the parameters.

The following tables show the mapping between input types.

#### [Input Type Mapping List for AL/AH]

Old model instrument (AL3000/AH3000)	Input Type (AL4000/AH4000)
Input Type	Input Type
-	Unused
1.mV:-13.80 to 13.80mV	01:mV (-13.80 to 13.80)
2.mV:-27.60 to 27.60mV	02:mV (-27.60 to 27.60)
3.mV:-69.00 to 69.00mV	03:mV (-69.00 to 69.00)
4.mV:-200.0 to 200.0mV	04:mV (-200.0 to 200.0)
5.mV:-500.0 to 500.mV	05:mV (-500.0 to 500.0)
6.V:-2.00 to 2.00V	06:V (-2.00 to 2.00)
7.V:-5.00 to 5.00V	07:V (-5.00 to 5.00)
8.V:-10.00 to 10.00V	08:V (-10.00 to 10.00)
9.V:-20.00 to 20.00V	09:V (-20.00 to 20.00)
10.V:-50.00 to 50.00V	10:V (-50.00 to 50.00)
13.mV:-6.90 to 6.90mV	13:mV (-6.900 to 6.900) * 1
14.mV:-55.00 to 55.00mV	03:mV (-69.00 to 69.00) * 1
21.K:-200.0 to 300.0°C	21:K (-200.0 to 300.0)
22.K:-200.0 to 600.0°C	22:K (-200.0 to 600.0)
23.K:-200 to 1370°C	23:K (-200 to 1370)
24.E:-200.0 to 200.0°C	24:E (-200.0 to 200.0)
25.E:-200.0 to 350.0°C	25:E (-200.0 to 350.0)
26.E:-200 to 900°C	26:E (-200 to 900)
27.J:-200.0 to 250.0°C	27:J (-200.0 to 250.0)
28.J:-200.0 to 500.0°C	28:J (-200.0 to 500.0)
29.J:-200 to 1200°C	29:J (-200 to 1200)
30.T:-200.0 to 250.0°C	30:T (-200.0 to 250.0)
31.T:-200.0 to 400.0°C	31:T (-200.0 to 400.0)
32.R:0 to 1200°C	32:R (0 to 1200)
33.R:0 to 1760°C	33:R (0 to 1760)
34.S:0 to 1300°C	34:S (0 to 1300)
35.S:0 to 1760°C	35:S (0 to 1760)
36.B:0 to 1820°C	36:B (0 to 1820)
37.N:-200.0 to 400.0°C	37:N (-200.0 to 400.0)
38.N:-200.0 to 750.0°C	38:N (-200.0 to 750.0)
39.N:-200 to 1300°C	39:N (-200 to 1300)
40.W-WRe0-26:0 to 2315°C	40:W-WRe26 (0 to 2315)
41.WRe5-WRe26:0 to 2315°C	41:WRe5-WRe26 (0 to 2315)
42.PR5-20:0 to 2315°C	Unused * 2
43.PtRh40-20:0 to 1880°C	43: PtRh40-20 (0 to 1880)

Old model instrument (AL3000/AH3000)	Input Type (AL4000/AH4000)
Input Type	Input Type
44.NiMo-Ni:0.0 to 290.0°C	44:NiMo-Ni (0.0 to 290.0)
45.NiMo-Ni:0.0 to 600.0°C	45:NiMo-Ni (0.0 to 600.0)
46.NiMo-Ni:0 to 1310°C	46:NiMo-Ni (0 to 1310)
47.CR-AuFe:0 to 280.0K	47:CR-AuFe (0.0 to 280.0)
48.Platinel2:-100.0 to 350.0°C	Unused * 2
49.Platinel2:-100.0 to 650.0°C	Unused * 2
50.Platinel2:-100 to 1390°C	Unused * 2
51.U:-200.0 to 250.0°C	51:U (-200.0 to 250.0)
52.U:-200.0 to 500.0°C	52:U (-200.0 to 500.0)
53.U:-200.0 to 600.0°C	53:U (-200.0 to 600.0)
54.L:-200.0 to 250.0°C	54:L (-200.0 to 250.0)
55.L:-200.0 to 500.0°C	55:L (-200.0 to 500.0)
56.L:-200 to 900°C	56:L (-200 to 900)
60.K:-140.0 to 160.0°C	21:K (-200.0 to 300.0) * 1
61.E:-60.0 to 100.0°C	24:E (-200.0 to 200.0) * 1
62.J:-90.0 to 120.0°C	27:J (-200.0 to 250.0) * 1
63.T:-150.0 to 150.0°C	63:T (-150.0 to 150.0)
64.N:-200.0 to 200.0°C	64:N (-200.0 to 200.0)
70.Pt100:-140.0 to 150.0°C	70:Pt100 (-140.0 to 150.0)
71.Pt100:-200.0 to 300.0°C	71:Pt100 (-200.0 to 300.0)
72.Pt100:-200.0 to 850.0°C	72:Pt100 (-200.0 to 850.0)
73.oPt100:-140.0 to 150.0°C	73:oPt100 (-140.0 to 150.0)
74.oPt100:-200.0 to 300.0°C	74:oPt100 (-200.0 to 300.0)
75.oPt100:-200.0 to 649.0°C	75:oPt100 (-200.0 to 649.0)
76.JPt100:-140.0 to 150.0°C	76:JPt100 (-140.0 to 150.0)
77.JPt100:-200.0 to 300.0°C	77:JPt100 (-200.0 to 300.0)
78.JPt100:-200.0 to 649.0°C	78:JPt100 (-200.0 to 649.0)
79.Pt50:-200.0 to 649.0°C	79:Pt50 (-200.0 to 649.0)
80.Pt-Co:4.0 to 374.0K	80:Pt-Co (4.0 to 374.0)
83.Pt100:-50.0 to 60.0°C	70:Pt100 (-140.0 to 150.0) * 1
84.Pt100:-200.0 to 650.0°C	72:Pt100 (-200.0 to 850.0) * 1
85.oPt100:-50.0 to 60.0°C	73:oPt100 (-140.0 to 150.0) * 1
86.JPt100:-50.0 to 60.0°C	76:JPt100 (-140.0 to 150.0) * 1
89.Cu53:0.0 to 200.0°C	Unused * 2
90.VIRTIS:1000 to 0MT	Unused * 2

[Input Type Mapping List for BL/BH]

Old model instrument (Old BL/old BH)	Input Type Switching	Input Type (KL4000/KH4000)	Old model instrument (Old BL/old BH)	Input Type Switching	Input Type (KL4000/KH4000)
Input Type		Input Type	Input Type		Input Type
1.mV:-7 to 7mV		01:mV (-13.80 to 13.80)	31.PR5-20:0 to 1800°C	Unused	* 2
2.mV:-14 to 14mV		02:mV (-27.60 to 27.60)	32.NiNiMo:0 to 1310°C	46:NiMo-Ni (0 to 1310)	* 1
3.mV:-25 to 25mV		02:mV (-27.60 to 27.60)	33.CR-AuFe:0 to 300K	Unused	* 2
4.mV:-70 to 70mV	Unused	* 2	34.P:-100 to 150°C	Unused	* 2
5.V:-5 to 5V	Unused	* 2	35.P:-100 to 300°C	Unused	* 2
10.K:-200 to 150°C	21:K (-200.0 to 300.0)	* 1	36.P:-100 to 600°C	Unused	* 2
11.K:-200 to 300°C	21:K (-200.0 to 300.0)	* 1	37.P:-100 to 1390°C	Unused	* 2
12.K:-200 to 600°C	22:K (-200.0 to 600.0)	* 1	38.U:-200 to 150°C	51:U (-200.0 to 250.0)	* 1
13.K:-200 to 1370°C	23:K (-200 to 1370)	* 1	39.U:-200 to 250°C	51:U (-200.0 to 250.0)	* 1
14.E:-200 to 350°C	25:E (-200.0 to 350.0)	* 1	40.U:-200 to 450°C	52:U (-200.0 to 500.0)	* 1
15.E:-200 to 900°C	26:E (-200 to 900)	* 1	41.U:-200 to 600°C	53:U (-200.0 to 600.0)	* 1
16.J:-200 to 400°C	28:J (-200.0 to 500.0)	* 1	42.L:-200 to 450°C	55:L (-200.0 to 500.0)	* 1
17.J:-200 to 1200°C	29:J (-200 to 1200)	* 1	43.L:-200 to 900°C	56:L (-200 to 900)	* 1
18.T:-200 to 150°C	30:T (-200.0 to 250.0)	* 1	50.Pt100:-50 to 50°C	69:Pt100 (-50.0 to 50.0)	* 1
19.T:-200 to 250°C	30:T (-200.0 to 250.0)	* 1	51.Pt100:-100 to 100°C	81:Pt100 (-100.0 to 100.0)	* 1
20.T:-200 to 400°C	31:T (-200.0 to 400.0)	* 1	52.Pt100:-140 to 150°C	70:Pt100 (-140.0 to 150.0)	* 1
21.R:0 to 1760°C	33:R (0 to 1760)	* 1	53.Pt100:-200 to 300°C	71:Pt100 (-200.0 to 300.0)	* 1
22.S:0 to 1760°C	35:S (0 to 1760)	* 1	54.Pt100:-200 to 649°C	84:Pt100 (-200.0 to 649)	* 1
23.B:0 to 1820°C	36:B (0 to 1820)	* 1	55.JPt100:-50 to 50°C	92:JPt100 (-50.0 to 50.0)	* 1
24.N:0 to 200°C	64:N (-200.0 to 200.0)	* 1	56.JPt100:-100 to 100°C	93:JPt100 (-100.0 to 100.0)	* 1
25.N:0 to 350°C	37:N (-200.0 to 400.0)	* 1	57.JPt100:-140 to 150°C	76:JPt100 (-140.0 to 150.0)	* 1
26.N:0 to 700°C	38:N (-200.0 to 750.0)	* 1	58.JPt100:-200 to 300°C	77:JPt100 (-200.0 to 300.0)	* 1
27.N:0 to 1300°C	39:N (-200 to 1300)	* 1	59.JPt100:-200 to 649°C	78:JPt100 (-200.0 to 649.0)	* 1
28.W5:0 to 2320°C	Unused	* 2	60.Pt50:-200 to 649°C	79:Pt50 (-200.0 to 649.0)	* 1
29.W0:0 to 2320°C	Unused	* 2	61.Pt-Co:4 to 374K	80:Pt-Co (4.0 to 374.0)	* 1
30.PR20-40:0 to 1880°C	43:PtRh40-20 (0 to 1880)	* 2			

## 8. Glossary

---

This section describes some terms used in this instruction manual.

No.	Terms	Description
1	parameter	Setting parameter.
2	format	Code representing the instrument model. Example: AH4724GDANN
3	overflow value	Value indicating that the upper limit of the range is exceeded. It is 32767.
4	communication adapter	Software component used for data transmission and reception.
5	USB driver	Tool, which is installed to a PC in advance, allowing you to perform data communication with an instrument connected to the PC with a USB cable.

## 9. Troubleshooting

This section describes problems with operations or functions of the software and their possible causes and remedies.

No.	Symptom	Cause/Remedy
1	Installation does not complete correctly.	Confirm that there is enough free hard disk space (refer to section 2-2).
2	The software does not start.	The installation might not be completed correctly. Uninstall and then reinstall the software, and check if the software can be started.
3	Parameters cannot be set.	Check if the format is correct.
4	The parameters of the connected instrument cannot be read.	(1) Check if [Online] is selected in [Select Online/Offline] (refer to section 6-2-3). (2) Check if the wiring is correct (refer to the instruction manual of the instrument). (3) Check if the connection cable breaks. (4) Check if the communication setting is correct (refer to section 6-3, 6-4, and 6-5).
5	Edited parameters cannot be written to the instrument.	(1) Check if the wiring is correct (refer to the instruction manual of the instrument). (2) Check if the connection cable breaks.
6	The software has been operating correctly, but suddenly a malfunction occurs.	Exit the software, and then start it again. * If the software exits due to an unexpected error, unsaved data would not be backed up. Please set it again.
7	A communication error occurs when connecting via USB.	Disconnect the USB cable and then re-connect it.

# **CHINO**

---

## **CHINO CORPORATION**

32-8, KUMANO-CHO, ITABASHI-KU, TOKYO 173-8632

Telephone: 81-3-3956-2171

Facsimile: 81-3-3956-0915

Printed in Japan